

DVD HOME THEATER SOUND SYSTEM DVX-1000

DVD RECEIVER/SUBWOOFER/SPEAKERS

DVR-1000/NX-SW1000/NX-P1000

SERVICE MANUAL

DVX-1000

- The DVX-1000 consists of the DVR-1000, NX-SW1000 and NX-P1000.
- When accepting a repair order from the user, it is recommended to receive DVR-1000, NX-SW1000 and NX-P1000 as a set for the repair work.
- DVX-1000は、DVR-1000、NX-SW1000 および NX-P1000 で構成されています。
- 修理依頼を受ける際、DVR-1000、NX-SW1000 および NX-P1000 を一緒にお預かりすることを推奨します。

IMPORTANT NOTICE

This manual has been provided for the use of authorized YAMAHA Retailers and their service personnel. It has been assumed that basic service procedures inherent to the industry, and more specifically YAMAHA Products, are already known and understood by the users, and have therefore not been restated.

WARNING: Failure to follow appropriate service and safety procedures when servicing this product may result in personal injury, destruction of expensive components, and failure of the product to perform as specified. For these reasons, we advise all YAMAHA product owners that any service required should be performed by an authorized YAMAHA Retailer or the appointed service representative.

IMPORTANT: The presentation or sale of this manual to any individual or firm does not constitute authorization, certification or recognition of any applicable technical capabilities, or establish a principle-agent relationship of any form.

The data provided is believed to be accurate and applicable to the unit(s) indicated on the cover. The research, engineering, and service departments of YAMAHA are continually striving to improve YAMAHA products. Modifications are, therefore, inevitable and specifications are subject to change without notice or obligation to retrofit. Should any discrepancy appear to exist, please contact the distributor's Service Division.

WARNING: Static discharges can destroy expensive components. Discharge any static electricity your body may have accumulated by grounding yourself to the ground buss in the unit (heavy gauge black wires connect to this buss).

IMPORTANT: Turn the unit OFF during disassembly and part replacement. Recheck all work before you apply power to the unit.

CONTENTS

TO SERVICE PERSONNEL	2-3
PREVENTION OF ELECTROSTATIC DISCHARGE	4
LOCALE MANAGEMENT INFORMATION	4
SYSTEM COMPOSITION / システム構成	5
FRONT PANELS	5-6
REAR PANELS	7-10
REMOTE CONTROL PANEL	11
SPECIFICATIONS / 参考仕様	12-14
INTERNAL VIEW	15
DISASSEMBLY PROCEDURES / 分解手順	16-20
PROTECTION INFORMATION DISPLAY / プロテクション情報の表示	21-22

SELF-DIAGNOSIS FUNCTION / 自己診断機能	23-30
AMP ADJUSTMENT	31
IC DATA	32-40
BLOCK DIAGRAMS	41-43
PIN CONNECTION DIAGRAM	44
PRINTED CIRCUIT BOARDS	45-58
SCHEMATIC DIAGRAMS	59-74
REPLACEMENT PARTS LIST	75-85
REMOTE CONTROL	86



このサービスマニュアルは、エコマーク認定の再生紙を使用しています。
This Service Manual uses recycled paper.



■ TO SERVICE PERSONNEL


1. Critical Components Information

Components having special characteristics are marked  and must be replaced with parts having specifications equal to those originally installed.

2. Leakage Current Measurement (For 120V Models Only)

When service has been completed, it is imperative to verify that all exposed conductive surfaces are properly insulated from supply circuits.

- Meter impedance should be equivalent to 1500 ohms shunted by 0.15μF.



- Leakage current must not exceed 0.5mA.
- Be sure to test for leakage with the AC plug in both polarities.

WARNING: CHEMICAL CONTENT NOTICE!

The solder used in the production of this product contains LEAD. In addition, other electrical/electronic and/or plastic (where applicable) components may also contain traces of chemicals found by the California Health and Welfare Agency (and possibly other entities) to cause cancer and/or birth defects or other reproductive harm.

DO NOT PLACE SOLDER, ELECTRICAL/ELECTRONIC OR PLASTIC COMPONENTS IN YOUR MOUTH FOR ANY REASON WHATSOEVER!

Avoid prolonged, unprotected contact between solder and your skin! When soldering, do not inhale solder fumes or expose eyes to solder/flux vapor!

If you come in contact with solder or components located inside the enclosure of this product, wash your hands before handling food.

About Lead Free Solder / 無鉛ハンダについて

All of the P.C.B.s installed in this unit and solder joints are soldered using the lead free solder.

Among some types of lead free solder currently available, it is recommended to use one of the following types for the repair work.

- Sn + Ag + Cu (tin + silver + copper)
- Sn + Cu (tin + copper)
- Sn + Zn + Bi (tin + zinc + bismuth)

Caution:

As the melting point temperature of the lead free solder is about 30°C to 40°C (50°F to 70°F) higher than that of the lead solder, be sure to use a soldering iron suitable to each solder.

本機に搭載されているすべての基板およびハンダ付けによる接合部は無鉛ハンダでハンダ付けされています。

無鉛ハンダにはいくつかの種類がありますが、修理時には下記のような無鉛ハンダの使用を推奨します。

- Sn+Ag+Cu (錫 + 銀 + 銅)
- Sn+Cu (錫 + 銅)
- Sn+Zn+Bi (錫 + 亜鉛 + ビスマス)

注意：

無鉛ハンダの融点温度は通常の鉛入りハンダに比べ30～40 °C程度高くなっていますので、それぞれのハンダに合ったハンダごてをご使用ください。

WARNING: Laser Safety

This product contains a laser beam component. This component may emit invisible, as well as visible radiation, which may cause eye damage. To protect your eyes and skin from laser radiation, the following precautions must be used during servicing of the unit.

- 1) When testing and/or repairing any component within the product, keep your eyes and skin more than 30 cm away from the laser pick-up unit at all times. Do not stare at the laser beam at any time.
- 2) Do not attempt to readjust, disassemble or repair the laser pick-up, unless noted elsewhere in this manual.
- 3) CAUTION : Use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

Laser Emitting conditions:


- 1) When the Top Cover is removed, and the STANDBY/ON SW is turned to the "ON" position, the laser component will emit a beam for several seconds to detect if a disc is present. During this time (5-10 sec.) the laser may radiate through the lens of the laser pick-up unit. Do not attempt any servicing during this period!
If no disc is detected, the laser will stop emitting the beam. When a disc is loaded, you will not be exposed to any laser emissions.
- 2) The laser power level can be adjusted with the VR on the pick-up PWB, however, this level has been set by the factory prior to shipping from the factory. Do not adjust this laser level control unless instruction is provided elsewhere in this manual. Adjustment of this control can increase the laser emission level from the device.

Laser Diode Properties


Type: Semiconductor laser GaAlAs
 Wave length: 650 nm (DVD)
 784 nm (VCD/CD)
 Output Power: 7 mW (DVD/VCD/CD)
 Beam divergence: 60 degree

WARNING

The use of optical instruments with this product will increase eye hazard.
 Repair handling should take place as much as possible with a disc loaded inside the player.



CAUTION VISIBLE AND INVISIBLE LASER RADIATION WHEN OPEN. AVOID EXPOSURE TO BEAM
ADVARSEL SYNLIG OG USYNLIG LASERSTRÅLING VED ÅBNING
 UNDGA UDSÆTTELSE FOR STRÅLING
ADVARSEL SYNLIG OG USYNLIG LASERSTRÅLING NÅR DEKSEL
 ÅPNES UNNGÅ EKSPONERING FOR STRÅLEN
VARNING SYNLIG OCH OSYNLIG LASERSTRÅLNING NÅR
 DENNA DEL ÄR ÖPPNAD BETRakta EJ STRÅLEN
VARO ! AVATTAESSA OLET ALTTIINA NÄKYVÄLLE JA
 NÄKYMÄTTÖMÄLLE LASER SÄTEILYLLE, ÄLÄ KATSO SÄTEESEEN
VORSICHT SICHTBARE UND UNSICHTBARE LASERSTRAHLUNG
 WENN ABDECKUNG GEÖFFNET NICHT DEM STRAHL AUSSETZEN
DANGER VISIBLE AND INVISIBLE LASER RADIATION WHEN
 OPEN AVOID DIRECT EXPOSURE TO BEAM
ATTENTION RAYONNEMENT LASER VISIBLE ET INVISIBLE EN
 CAS D'OUVERTURE EXPOSITION DANGEREUSE AU FAISCEAU



Warning for power supply

The primary side of the power supply carries live mains voltage when the player is connected to the mains even when the player is switched off !

This primary area is not shielded so it is possible to touch copper tracks and/or components when servicing the player.
 Service personnel have to take precautions to prevent touching this area or components in this area.

Note:

The screws on the DVD mechanism may never be touched, removed or re-adjusted.
 Handle the DVD mechanism with care when the unit has to be exchanged!
 The DVD mechanism is very sensitive for dropping or giving shocks.

■ PREVENTION OF ELECTROSTATIC DISCHARGE

The laser diode in the DVD mechanism may be damaged due to static electricity from clothes or the human body. Use caution to prevent electrostatic damage when servicing or handling the DVD-mechanism.

1. Grounding for electrostatic damage prevention


Some devices, such as the DVD player, use an optical pickup (laser diode) that will be damaged by static electricity in the working environment. Only attempt service after ensuring that all grounding procedures have been completed.

1. Worktable grounding

Put a grounded conductive material (sheet) or iron sheet on the area where the optical pickup is placed.

2. Human body grounding

Use an anti-static wrist strap to discharge the static electricity from your body.




2. Handling Precautions for DVD mechanism

1. Handle the DVD mechanism gently, as it is an extremely high-precision assembly.
2. The flexible cable lines may break if an excessive force is applied to it. Use caution when handling the cable.
3. The semi-fixed resistor for laser power adjustment should not be adjusted. Do not turn the resistor.

■ LOCALE MANAGEMENT INFORMATION

Locale Management Information : This DVD player is designed and manufactured to respond to the Locale Management Information that is recorded on a DVD disc. If the Locale number described on the DVD disc does not correspond to the Locale number of this DVD player, this DVD player cannot play this disc.

This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited.




■ SYSTEM COMPOSITION / システム構成

The DVX-1000 consists of the DVR-1000, NX-XSW1000 and NX-P1000.


DVX-1000 は、DVR-1000、NX-SW1000 および NX-P1000 で構成されています。

▼ DVX-1000



■ FRONT PANELS


DVR-1000




DVX-1000

NX-SW1000

Front view




Side view




NX-P1000

Front view



Side view




REAR PANELS


▼ R, K, A, L models

DVR-1000

Rear view




Bottom view




▼ G model

Rear view



Bottom view



DVR-1000

[illegible]

The image shows the back of a Yamaha DXV-1000 laser disc player. The device is rectangular with a light-colored faceplate. On the left side, there are two vertical columns of ventilation slots. On the right side, there is a single vertical column of ventilation slots. In the center, there are several warning and technical labels. The top label is a yellow warning label with black text and symbols. Below it is a white label with black text and symbols. To the right of these labels is a small black rectangular label with white text. Below that is a white label with black text. At the bottom center, there is a small white label with black text. The device is mounted on a black surface, and there are four screws visible at the corners.

YAMAHA
MODEL NO. DXV-1000
230 VOLTS 15 WATTS
50/60 Hz
YAMAHA CORPORATION
MADE IN CHINA

CAUTION
DO NOT OPEN
ATTENTION: NE PAS
OUVRIR LE COUVERCLE
NE PAS OUVRIRE

MANUFACTURED UNDER LICENSE FROM GULLEY
LABORATORIES, "GULLEY" "PRODUCED" AND
THE DOUBLE-D SYMBOL ARE TRADEMARKS
OF GULLEY LABORATORIES

CLASS 1 LASER PRODUCT
LASER KLASSE 1 PRODUKT
LÁZERN 1 LASERKLASSE
KLASSE 1 LASER APPARAT
PRODUIT LASER DE CLASSE 1

SPENCER CLARK, U.S. PATENT NO. 4,310,000
4,310,001, 4,310,002 AND 4,310,003
U.S. PATENT NOS. 4,310,000, 4,310,001, 4,310,002
AND 4,310,003

DO NOT OPEN - DO NOT
REOPEN - DO NOT
REOPEN - DO NOT
REOPEN - DO NOT

Rear view


The rear panel of the VCR features the following connections and controls from left to right:

- MAIN:** A large rectangular port for the main power connection.
- SYSTEM CONNECTOR:** A port for connecting to a hi-fi system.
- OPTICAL:** A port for optical audio output.
- AUX IN:** A port for auxiliary audio input.
- LINE OUT:** A port for line-level audio output.
- AUDIO:** A set of four circular ports for stereo audio output (Left and Right channels).
- COMPONENT:** A set of four circular ports for component video output (Y, Pb, Pr, and a common ground).
- VIDEO:** A port for standard video output.
- VIDEO OUT (DVD ONLY):** A port for video output from a DVD player.
- D/O OR MONITOR OUT (DVD ONLY):** A port for digital output or monitor output from a DVD player.
- LICENSED AAC PATENTS:** A label indicating that the VCR uses AAC technology, with a reference to the instruction manual for patent notice.
- TUNER:** A port for the tuner, including FM/ANT and 75Ω UNBAL. connections.
- FM ANT:** A port for the FM antenna.
- 75Ω UNBAL.:** A port for the 75Ω unbalanced video output.
- FM ANT:** A port for the FM antenna.
- 75Ω UNBAL.:** A port for the 75Ω unbalanced video output.
- FM ANT:** A port for the FM antenna.
- 75Ω UNBAL.:** A port for the 75Ω unbalanced video output.


[illegible]

NX-SW1000


▼ R model




▼ K model



▼ A model




▼ G, F models




NX-SW1000

▼ L model




▼ J model




NX-P1000

Rear view




Bottom view




■ REMOTE CONTROL PANELS

▼ R, K, A, L, J models



▼ G, F models



SPECIFICATIONS / 参考仕様

DVR-1000

TUNER SECTION / チューナー部

FM Tuning Range / FM 受信周波数範囲	
R, K, A, G, F, L models	87.50 to 108.00 MHz
J model	76.0 to 90.0 MHz
AM Tuning Range / AM 受信周波数範囲	
K, A, G, F, J models	531 to 1602 kHz
R, L models	531 to 1602 kHz/530 to 1700 kHz

DISC SECTION / ディスク部

Laser Type / レーザータイプ	Semiconductor / 半導体
Disc Diameter / ディスク直径	12cm
Video Decoding / ビデオデコード	MPEG-1 / MPEG-2 / DivX 3.11, 4.x & 5.x / DivX Ultra
Video DAC / ビデオ D A C	12 bits/108 MHz
Signal System / 映像信号方式	PAL / NTSC
Video Format / ビデオフォーマット	4:3 / 16:9
Composite Video Output / コンポジットビデオ出力	1.0 Vp-p, 75 ohms
S-video Output / S ビデオ出力	Y - 1.0 Vp-p, 75 ohms C - 0.3 Vp-p, 75 ohms
RGB (SCART) Output	0.7 Vp-p, 75 ohms
Component Video Output / コンポーネントビデオ出力	Y - 1.0 Vp-p, 75 ohms Pb/Cb Pr/Cr - 0.7 Vp-p, 75 ohms
Audio DAC / オーディオDAC	24 bits / 192 kHz
Frequency Response / 再生周波数帯域	4 Hz to 20 kHz (44.1 kHz) 4 Hz to 22 kHz (48 kHz) 4 Hz to 44 kHz (96 kHz)
Audio S/N / オーディオS/N 比	100 dB
Distortion / 全高調波歪率	0.0035 %
Dynamic Range / ダイナミックレンジ	90 dB

AUDIO FORMAT / オーディオフォーマット

Digital	Dolby Digital/DTS/MPEG Compressed Digital
PCM	16, 20, 24 bits fs 44.1, 48, 88.2, 96, 176.4, 192 kHz
MP3 (ISO 9660)	24, 32, 56, 64, 96, 128, 256 kbps fs 16, 22.05, 24, 32, 44.1, 48 kHz
WMA	32 to 192 kbps, mono, stereo
Full decoding of Dolby Digital and DTS multi-channel sound/ Dolby Surround Compatible Downmix from Dolby Digital multi-channel sound	

GENERAL / 総合

Power Supply Rating / 電源電圧	
R model	220-240 V, 50/60 Hz
K model	220 V, 60 Hz
A model	240 V, 50 Hz
G, F models	230 V, 50 Hz
L model	110-120 V, 50/60 Hz
J model	100 V, 50/60 Hz
Power Consumption / 消費電力	
	26 W (Max.) / (最高) 0.5 W (Standby) / (スタンバイ)
Frequency Response	20 Hz to 20 kHz±0.2 dB
Signal to Noise Ratio	> 100 dB
Input Sensitivity	SCART In (G, F models only) 500 mV
HDMI Output / HDMI 出力	Type A
USB	Type A
AUX IN (Stereo mini) / AUX IN (ステレオミニ)	ø3.5 mm mini jack / ミニジャック
Dimensions / 外形寸法 (W x H x D)	435 x 78 (rear)/38 (front) x 208 mm (17-1/8" x 3-1/16"/1-1/2" x 8-3/16")
Weight / 質量	3.2 kg (7 lbs. 1 oz.)
Finish / 仕上げ	Black color
Accessories / 付属品	Remote Control x1 Battery x2 Indoor FM Antenna x1 AM Loop Antenna x1 Video Pin Cable (1.5m) x1 Power Cable (1.5m) x1

* **Specifications subject to change without prior notice.**
仕様および外観は、改良のため予告なく変更することがあります。

NX-SW1000**AMPLIFIER SECTION / アンプ部****Output Power / 実用最大出力**

R, K, A, L models

120/240V

L/R	70W+70W (1KHz 0.9% L+R)
	90W+90W (1KHz 10% L+R)
Subwoofer	80W (100Hz 0.9%)
	100W (100Hz 10%)

110/220V

L/R	60W+60W (1KHz 0.9% L+R)
	75W+75W (1KHz 10% L+R)
Subwoofer	70W (100Hz 0.9%)
	90W (100Hz 10%)

G, F models

L/R	70W+70W (1KHz 0.7% L+R)
	90W+90W (1KHz 10% L+R)
Subwoofer	80W (100Hz 0.9%)
	100W (100Hz 10%)

J model

L/R	90W+90W (1KHz 10%)
Subwoofer	100W (100Hz 10%)

GENERAL / 総合**Power Supply Rating / 電源電圧**

R, K, A, L models	110-120/220-240V, 50/60Hz
G and F models	230 V, 50 Hz
J model	100V, 50/60Hz

Power Consumption / 消費電力

200 W

System / 型式

Advanced Yamaha Active
Servo Technology
アドバンスドヤマハアクティブ
サーボテクノロジー

Impedance / インピーダンス

6 ohms

Speaker Driver / スピーカーユニット

16cm cone woofer, magnetic
shielding type
16cm コーンウーファー(防磁型)

Frequency Response / 再生周波数帯域

35Hz – 100Hz (-10dB)

Input Sensitivity / 入力感度

AUX In 300 mV

Dimensions / 外形寸法(W x H x D)

230 x 477 x 440 mm
(9-1/16" x 18-3/4" x 17-5/16")

Weight / 質量

16.0 kg (35 lbs. 4 oz.)

Finish / 仕上げ

Black color

Accessories / 付属品

System Control Cable (4m) x1
Power Cable (1.5m) x1 (R, K, A, L models)

*** Specifications subject to change without prior notice.**

仕様および外観は、改良のため予告なく変更することがあります。

NX-P1000**System / 型式**

2-way acoustic suspension speaker system

2ウェイ密閉式

Impedance / インピーダンス

6 ohms

Speaker Drivers / スピーカーユニット

11.0cm woofer, magnetic shielding type
+ 2.5cm soft dome tweeter, magnetic
shielding type
11.0 cm ウーファー(防磁型) +
2.5cm ソフトドームツイーター(防磁型)

Frequency Response / 再生周波数帯域

100 Hz – 20 kHz (-10dB)

Dimensions / 外形寸法 (W x H x D)

145 x 262 x 178 mm
(5-11/16" x 10-5/16" x 7")

Weight / 質量

2.9 kg (6 lbs. 6 oz.)

Finish / 仕上げ

Black color

Accessories / 付属品

Speaker Cable (4m) x2

*** Specifications subject to change without prior notice.**

仕様および外観は、改良のため予告なく変更することがあります。

R General model**F Russian model****K Korean model****L Singapore model****A Australian model****J Japanese model****G European model**



Manufactured under license from Dolby Laboratories. "Dolby", "Pro Logic", "MLP Lossless" and the double-D symbol are trademarks of Dolby Laboratories.

ドルビーラボラトリーズからの実施権により製造されています。「ドルビー」及びダブルD記号は、ドルビーラボラトリーズの商標です。



"DTS" and "DTS Digital Surround" are registered trademarks of DTS, Inc.

DTS およびDTS Digital Out はデジタルシアターシステムズの登録商標です。



DivX, DivX Ultra Certified, and associated logos are trademarks of DivX, Inc. and are used under license.



DivX、DivX Ultra Certified、および関連するロゴは、DivX, Inc. の商標です。これらの商標は、DivX, Inc. の使用許諾を得て使用しています。



"DCDi" is a trademark of Faroudja, a division of Genesis Microchip, Inc.

DCDi は、Genesis Microchip Inc. の事業部門である Faroudja の商標です。



HDMI, the HDMI logo and High Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.

HDMI、HDMI ロゴおよび High-Definition Multimedia Interface は、HDMI Licensing LLC の商標または、登録商標です。




This subwoofer system (NX-SW1000) employs Advanced Yamaha Active Servo Technology which Yamaha has developed for reproducing higher quality super-bass sound.




AAC ロゴマークはドルビーラボラトリーズの商標です。

DIMENSIONS


● DVR-1000



● NX-SW1000



● NX-P1000




Unit : mm (inch)

INTERNAL VIEW

DVR-1000


Top view




- ① FRONT (1) P.C.B.
- ② FRONT (4) P.C.B.
- ③ FRONT (2) P.C.B.
- ④ FRONT (5) P.C.B.
- ⑤ AM/FM TUNER
- ⑥ USB P.C.B.
- ⑦ MONO P.C.B.
- ⑧ AV P.C.B.
- ⑨ POWER SUPPLY UNIT
- ⑩ HDMI P.C.B.
- ⑪ LOADER ASS'Y
- ⑫ FRONT (3) P.C.B.

NX-SW1000

Front view



Rear view



- ① DRIVER WOOFER
- ② MAIN (1) P.C.B.
- ③ DSP (1) P.C.B.
- ④ DSP (3) P.C.B.
- ⑤ DSP (2) P.C.B.
- ⑥ POWER TRANSFORMER
- ⑦ MAIN (2) P.C.B.
- ⑧ MAIN (4) P.C.B.
- ⑨ MAIN (3) P.C.B.

■ DISASSEMBLY PROCEDURES / 分解手順

(Remove parts in the order as numbered.)

(番号順に部品を取り外してください。)

DVR-1000

1. Removal of Top Cabinet

- Remove 6 screws (①) and 2 screws (②). (Fig. 1)
- Release 4 hooks and then pull out the top cabinet slowly. (Fig. 2)
- Remove 1209, 1303 and CN3. (Fig. 2)
- Remove the top cabinet. (Fig. 2)




Fig. 1

2. Removal of Loader Ass'y

- Remove screw (③) and screw (④). (Fig. 3)
- Remove 1100 and 1103. (Fig. 3)
- Remove the USB P.C.B.. (Fig. 3)
- Remove 2 screws (⑤) and 2 screws (⑥). (Fig. 3)
- Unlock 1101 and then disconnect the flexible flat cable, and ground the terminal face of the flexible flat cable with a clip or the like. (Fig. 3)
- Remove 1102, 1104, 1105 and 1110. (Fig. 3)
- Unlock 1301, 1302 and 1304 and then disconnect the flexible flat cable. (Fig. 3)
- Remove MONO P.C.B. together with the support MPEG. (Fig. 3)
- Remove 4 screws (⑦). (Fig. 3)
- Remove the loader ass'y. (Fig. 3)

1. トップキャビネットの外し方

- ① のネジ 6 本、② のネジ 2 本を外します。 (Fig. 1)
- フック 4 箇所を外し、トップキャビネットをゆっくり外します。 (Fig. 2)
- 1209、1303、CN3 を外します。 (Fig. 2)
- トップキャビネットを取り外します。 (Fig. 2)




Fig. 2

2. ローダー ASSY の外し方

- ③ のネジ 1 本、④ のネジ 1 本を外します。 (Fig. 3)
- 1100、1103 を外します。 (Fig. 3)
- USB PCB を取り外します。 (Fig. 3)
- ⑤ のネジ 2 本、⑥ のネジ 2 本を外します。 (Fig. 3)
- 1101 のロックを解除してカード電線を外します。次に外したカード電線のクリップ等で端子面をアースします。 (Fig. 3)
- 1102、1104、1105、1110 を外します。 (Fig. 3)
- 1301、1302、1304 のロックを解除してカード電線を外します。 (Fig. 3)
- MONO P.C.B. をサポート MPEG と一緒に取り外します。 (Fig. 3)
- ⑦ のネジ 4 本を外します。 (Fig. 3)
- ローダー ASSY を取り外します。 (Fig. 3)




Fig. 3

* How to manually eject a disc

If the inserted disc cannot be ejected, it is possible to eject it manually.

- a. Remove the Loader ass'y. (Refer to Disassembly Procedures)
- b. Turn the loading gear in the arrow direction until the disc is ejected. (Fig. 4)

* 手動でディスクを取り出す方法

挿入したディスクが取り出せない場合、手動で取り出すことができます。

- a. ローダー ASSY を取り外します。(分解手順参照)
- b. ディスクが取り出せるまで、ローディングギアを矢印の方向に回します。(Fig. 4)




Fig. 4

Disassembly Procedure of Front section

1. Removal of Front Panel Sub Ass'y

- * The front panel sub ass'y is fixed to the cabinet ass'y with dowels.

As a flatblade screwdriver and metalblade or the like are used for removal, give special care not to cause damage to the cabinet ass'y.

- First, insert a flatblade screwdriver at 2 locations on the bottom to push up the front panel sub ass'y. (Fig. 6)
- Then, using a metalblade or the like, push up the front panel sub ass'y to remove it. (Fig. 6)

Notes:

- When removing the front panel sub ass'y, use both flatblade screwdriver and the metalblade on the like to prevent possible deformation of the front panel sub ass'y.
- When installing the front panel sub ass'y, apply quick-drying bond or the like to dowels and then fit them into dowel holes for secure installation.
(The front grille ass'y will come off easily without quick-drying bond or the like.)

2. Removal of Driver Woofer

- Remove 4 screws (①). (Fig. 6)
- Pull out the driver woofer.
- Disconnect the connector connected to the terminal of the driver woofer. (Fig. 6)
- Remove the driver woofer. (Fig. 6)

フロント部の分解手順

1. F パネルサブ ASSY の外し方

- * F パネルサブ ASSY はキャビネット ASSY にダボで固定されています。

マイナスドライバーおよびヘラ等を使って取り外す場合、キャビネット ASSY に傷が付かないよう十分注意してください。

- 最初に、底面の 2 箇所へマイナスドライバを差し込み、F パネルサブ ASSY を押し上げます。(Fig. 6)
- 次に、ヘラ等を使い、F パネルサブ ASSY を押し上げ、取り外します。(Fig. 6)

注意：

- F パネルサブ ASSY を取り外すとき、ヘラ等を使わずマイナスドライバーのみで取り外すと F パネルサブ ASSY が壊れてしまいます。
- F パネルサブ ASSY を取り付けるとき、F パネルサブ ASSY のダボに速乾ボンド塗って差し込み、取り付けください。
(速乾ボンド塗らずに F パネルサブ ASSY を差し込むだけでは、簡単に外れてしまいます。)

2. スピーカーユニットの外し方

- ① のネジ 4 本を外します。(Fig. 6)
- スピーカーユニットを引き出します。(Fig. 6)
- スピーカーユニットの端子からコネクターを外します。(Fig. 6)
- スピーカーユニットを取り外します。(Fig. 6)




Fig. 6

Disassembly Procedure of Rear section

1. Removal of Rear Panel Ass'y

- Remove 8 screws (①). (Fig. 7)
- Remove the rear cover. (Fig. 7)
- Remove 6 screws (②). (Fig. 7)
- Pull out the rear panel ass'y slowly. (Fig. 7)
- Remove CB15. (Fig. 7)
- Remove the rear panel ass'y. (Fig. 7)

When Checking the P.C.B.:

- Connect all the removed connectors during disassembly back to its original positions.
- Spread the rubber sheet and cloth for insulation purpose and place the rear panel ass'y on them. (Fig. 8)




Fig. 7

リア部の分解手順

1. リアパネル ASSY の外し方

- ① のネジ 8 本を外します。 (Fig. 7)
- リアカバーを取り外します。 (Fig. 7)
- ② のネジ 6 本を外します。 (Fig. 7)
- リアパネル ASSY をゆっくり引き出します。 (Fig. 7)
- CB15 を外します。 (Fig. 7)
- リアパネル ASSY を取り外します。 (Fig. 7)

P.C.B. をチェックをする場合には：

- 外したケーブル（コネクター）をすべて元に戻します。
- ゴムシートと布を敷き、その上にリアパネルASSYを置いてチェックします。 (Fig. 8)




Fig. 8

1. Removal of Cover Bottom Ass'y

a. Remove 4 nonskid pads. (Fig. 9)

* *The old nonskid pad once removed cannot be reused. Be sure to replace them with new ones.*

b. Remove 4 screws (①) and 2 screws (②). (Fig. 9)

c. Pull out the cover bottom ass'y downward gradually. (Fig. 10)

d. Disconnect 6 connectors and then remove cover bottom ass'y. (Fig. 10)

Note: Make sure that all the removed connectors parts are reinstalled at specified positions.

2. Removal of Front Panel Ass'y

a. Remove 4 screws (③). (Fig. 10)

b. Slide the lower part of the front panel ass'y forward gradually and remove it from 4 dowels. (Fig. 3)

* *At this time, use care not to cause damage to the hook in the upper part of the front panel ass'y.*

* *When installing the front panel ass'y, fit the hook in its upper part first and then install it by 4 dowels.*

3. Removal of Driver Woofer

a. Remove 4 screws (④) and then remove the driver woofer. (Fig. 10)

1. カバーボトム ASSY の外し方

a. 滑り止めパッド 4 個を外します。 (Fig. 9)

* **一度取り外した滑り止めパッドは使用できません。必ず、新しい滑り止めパッドに交換してください。**

b. ① のネジ 4 本、② のネジ 2 本を外します。 (Fig. 9)

c. カバーボトム ASSY を下方へゆっくり引き出します。 (Fig. 10)

d. コネクター 6 個を外し、カバーボトム ASSY を取り外します。 (Fig. 10)

注意: 取り外したコネクターはすべて決められた位置に取り付けてください。

2. フロントパネル ASSY の外し方

a. ③ のネジ 4 本を外します。 (Fig. 10)

b. フロントパネル ASSY の下側を前方にゆっくりスライドさせ、ダボ 4 箇所を外します。 (Fig. 3)

* **このとき、フロントパネル ASSY の上側のフックを壊さないように注意してください。**

* **フロントパネル ASSY を取り付ける場合は、最初に上側のフックを差し込み、次にダボ 4 箇所へ取り付けます。**

3. スピーカーユニット(ウーファー)の外し方

a. ④ のネジ 4 本を外し、スピーカーユニット(ウーファー)を取り外します。 (Fig. 10)




Fig. 9




Fig. 10

NX-SW1000


PROTECTION INFORMATION DISPLAY / プロテクション情報の表示

Connect the DVR-1000 system connector and NX-SW1000 system connector by using the system cable and then connect the power cables of DVR-1000 and NX-SW1000 to AC outlets.

Turn on the power by pressing the STANDBY/ON key of DVR-1000 or STANDBY/ON key of the remote controller. At this time, if the indicator for service on the rear panel of NX-SW1000 is flashing, the normal operation is not available because the protection function is at work.

The protection information is provided by the indicator for service on the rear panel of NX-SW1000.

DVR-1000のシステムコネクターとNX-SW1000のシステムコネクターをシステムケーブルで接続し、DVR-1000とNX-SW1000の電源コードをACコンセントに接続します。DVR-1000のSTANDBY/ONキーまたはリモコンのSTANDBY/ONキーを押し電源オンしたとき、NX-SW1000リアパネルのサービス用インジケータが点滅表示している場合、プロテクションが動作しているため正常動作させることができません。プロテクションの情報は、NX-SW1000リアパネルにあるサービス用インジケータを使って表示します。



Displayed / 表示 (★ : Flashing / 点滅, ● : Off / 消灯)				Types of protection function / プロテクションの種類
D300	D301	D302	D303	
●	●	●	●	Normal (no protection function) / 正常(プロテクション無し)
●	●	●	★	I protection / 過電流プロテクション
●	●	★	●	PS1 protection / 電源電圧1プロテクション
●	●	★	★	PS2 protection / 電源電圧2プロテクション
●	★	●	●	PS3 protection / 電源電圧3プロテクション
●	★	●	★	THM protection / 温度プロテクション
●	★	★	●	AMP DC protection / アンプDCプロテクション

● Details of Protection Information

1. I protection

Cause : Excess current flow into amplifier
Detection port : PRI (DSP P.C.B. 73 pin of microprocessor IC13)
Detected at : Amplifier output of MAIN P.C.B.

2. PS1 protection

Cause : The voltage in the power supply section is abnormal.
Detection port : PRV1 (DSP P.C.B. 95 pin of microprocessor IC13)
Detected at : +12V (IC10 of MAIN P.C.B.), -12V (IC11 of MAIN P.C.B.), +5V (IC12 of MAIN P.C.B.)

3. PS2 protection

Cause : The voltage in the power supply section is abnormal.
Detection port : PRV2 (DSP P.C.B. 94 pin of microprocessor IC13)
Detected at : AC2 (D23 of MAIN P.C.B.), +5V (IC12 of MAIN P.C.B.)

3. PS3 protection

Cause : The voltage in the power supply section is abnormal.
Detection port : PRV3 (DSP P.C.B. 93 pin of microprocessor IC13)
Detected at : AC1 (D24 of MAIN P.C.B.), +5V (IC12 of MAIN P.C.B.)

4. THM protection

Cause : Abnormal temperature of heat sink.
Detection port : THM (DSP P.C.B. 92 pin of microprocessor IC13)
Detected at : IC14 of MAIN P.C.B.

5. AMP DC protection

Cause : Abnormal DC voltage of amplifier output L/R/SW.
Detection port : PRD (DSP P.C.B. 97 pin of microprocessor IC13)
Detected at : SPE_L of speaker output L, SPE_R of speaker output R, SP- of subwoofer output.

● プロテクション情報の詳細

1. 過電流プロテクション

原因 : アンプ部に過電流が流れた。
検出ポート : PRI (DSP P.C.B. マイコンIC13の73ピン)
検出先 : MAIN P.C.B.のアンプ出力

2. 電源電圧1プロテクション

原因 : 電源部の電圧が異常。
検出ポート : PRV1 (DSP P.C.B. マイコンIC13の95ピン)
検出先 : +12V (IC10 MAIN P.C.B.), -12V (IC11 MAIN P.C.B.), +5V (IC12 MAIN P.C.B.)

3. 電源電圧2プロテクション

原因 : 電源部の電圧が異常。
検出ポート : PRV2 (DSP P.C.B. マイコンIC13の94ピン)
検出先 : AC2 (D23 MAIN P.C.B.), +5V (IC12 MAIN P.C.B.)

3. 電源電圧3プロテクション

原因 : 電源部の電圧が異常。
検出ポート : PRV3 (DSP P.C.B. マイコンIC13の93ピン)
検出先 : AC1 (D24 MAIN P.C.B.), +5V (IC12 MAIN P.C.B.)

4. 温度プロテクション

原因 : ヒートシンクの温度が異常。
検出ポート : THM (DSP P.C.B. マイコンIC13の92ピン)
検出先 : IC14 MAIN P.C.B.

5. アンプDCプロテクション

原因 : アンプ出力L/R/SWのDC電圧が異常。
検出ポート : PRD (DSP P.C.B. マイコンIC13の97ピン)
検出先 : SPE_L (スピーカー出力L)、SPE_R (スピーカー出力R)、SP- (サブウーファー出力)

NX-SW1000

■ SELF-DIAGNOSTIC FUNCTION / 自己診断機能（ダイアグ）

* It is not possible to activate the self-diagnostic function while the protection function is at work.

* To operate the self-diagnostic function, prepare DVR-1000, NX-SW1000, system cable and remote controller in advance.

* プロテクションが動作しているときにダイアグを起動することはできません。

* ダイアグ（自己診断機能）を操作するときには、DVR-1000、NX-SW1000、システムケーブルおよびリモコンを用意してください。

There are 14 main menu items, each of which has submenu items.

Listed in the table below are menu items and sub-menu items.

メインメニューは14個あり、そのそれぞれにサブメニューがあります。

下表はメニュー一覧です。

Displayed / 表示 (*1)				No.	Main menu	Sub-menu
D300	D301	D302	D303			
●	●	●	★	1	DSP THROUGH 1	1 MASTER Vol. -90 dB 2 MASTER Vol. -40 dB 3 MASTER Vol. -20 dB 4 MASTER Vol. -0 dB
●	●	★	●	2	MUTE CHECK	1 MUTE OFF (Vol. -20 dB) 2 SPEAKERS MUTE 3 FRONT L/R MUTE 4 SUBWOOFER MUTE
●	●	★	★	3	RESERVED (Not applied to this model / このモデルには適応されません)	
●	★	●	●	4	OUTPUT PORT CHECK	1 (Not applied to this model / このモデルには適応されません) 2 (Not applied to this model / このモデルには適応されません) 3 PATTERN 1 4 PATTERN 2
●	★	●	★	5	TEST TONE	1 ALL CHANNEL 2 TURN CHANGEOVER 3 SUBWOOFER 4 FRONT L/R 1kHz, SUBWOOFER 100Hz
●	★	★	●	6	RESERVED (Not applied to this model / このモデルには適応されません)	
●	★	★	★	7	DEVICE CHECK	1 DEVICE CHECK 2 (Not applied to this model / このモデルには適応されません) 3 (Not applied to this model / このモデルには適応されません) 4 (Not applied to this model / このモデルには適応されません)
★	●	●	●	8	CPU INFORMATION	1 FIRMWARE VERSION 2 (Not applied to this model / このモデルには適応されません) 3 SERIAL VERSION BIT 4-7 4 SERIAL VERSION BIT 3-0
★	●	●	★	9	EMC TEST	1 EMC TEST 2 (Not applied to this model / このモデルには適応されません) 3 (Not applied to this model / このモデルには適応されません) 4 (Not applied to this model / このモデルには適応されません)

Displayed / 表示 (*1)				No.	Main menu	Sub-menu
D300	D301	D302	D303			
★	●	★	●	10	RESERVED (Not applied to this model / このモデルには適応されません)	
★	●	★	★	11	RESERVED (Not applied to this model / このモデルには適応されません)	
★	★	●	●	12	RESERVED (Not applied to this model / このモデルには適応されません)	
★	★	●	★	13	DSP PROGRAM WRITING	1 READY FOR WRITING
						2 (Not applied to this model / このモデルには適応されません)
						3 (Not applied to this model / このモデルには適応されません)
						4 WRITING START
★	★	★	●	14	RESERVED (Not applied to this model / このモデルには適応されません)	

*1..... ★ : Flashing / 点滅, ● : Off / 消灯

● Starting Self-Diagnostic Function

Connect the DVR-1000 system connector and NX-SW1000 system connector by using the system cable and then connect the power cables of DVR-1000 and NX-SW1000 to AC outlets.

Next, turn on the power by pressing the STANDBY/ON key of DVR-1000 or STANDBY/ON key of the remote controller while pressing the key for service (SW300) on the rear panel of NX-SW1000.


At this time, keep pressing the key for service (SW300) on the rear panel of NX-SW1000 for 5 seconds or longer. All indicators for service flash 5 times and remain on when the self-diagnostic function mode is activated.

● ダイアグの起動

DVR-1000のシステムコネクタとNX-SW1000のシステムコネクタをシステムケーブルで接続し、DVR-1000とNX-SW1000の電源コードをACコンセントに接続します。

次に、NX-SW1000リアパネルのサービス用キー (SW300) を押しながらDVR-1000のSTANDBY/ONキーまたはリモコンのSTANDBY/ONキーを押し、電源オンします。

このとき、NX-SW1000リアパネルのサービス用キー (SW300) を約5秒以上押し続けてください。すべてのサービス用インジケータが5回点滅をして、ダイアグモードに入ると点灯します。



NX-SW1000

● Canceling Self-Diagnostic Function

Turn off the power by pressing the STANDBY/ON key of this unit or the “STANDBY/ON” key of the remote control.

● Operation procedure of Main menu and Sub-menu

There are 14 menu items, each of them having sub-menu items.

* *Set the mode to DVD/CD by pressing the DVD/CD key on the remote controller.*

Main menu selection

To select the main menu, press the key for on the rear panel of NX-SW1000 or the MENU key on the remote controller.

Sub-menu selection

To select the sub-menu, press the applicable numeric key among 1 to 4 on the remote controller.

Numeric “1” key: Select the sub-menu No. 1

Numeric “2” key: Select the sub-menu No. 2

Numeric “3” key: Select the sub-menu No. 3

Numeric “4” key: Select the sub-menu No. 4

● ダイアグの解除

DVR-1000のSTANDBY/ONキーまたはリモコンのSTANDBY/ONキーを押し、電源オフします。

● メインメニューとサブメニューの操作

ダイアグにはNo. 1～14のメニューがあり、そのそれぞれにサブメニューがあります。

* リモコンのDVD/CDキーを押し、モードをDVD/CDにします。

メインメニューの選択

NX-SW1000リアパネルのサービス用キーまたはリモコンのMENUキーを押し、メインメニューを選択します。

サブメニューの選択


リモコンの数字キーの1～4を押してサブメニューを選択します。

数字キー 1: サブメニュー1を選択します。

数字キー 2: サブメニュー2を選択します。

数字キー 3: サブメニュー3を選択します。

数字キー 4: サブメニュー4を選択します。



● Details of Self-Diagnostic Function menu

1. DSP THROUGH

The output level can be selected by using SUB-MENU.
The signal is output in digital full bit without including the head margin.

1-1 MASTER VOLUME -90 dB

Input level (AUX IN)	SPEAKER OUTPUT (1 kHz) FRONT L/R	SUBWOOFER (50Hz)
Both ch, -20 dBm	- ∞	- ∞

1-2 MASTER VOLUME -40 dB

Input level (AUX IN)	SPEAKER OUTPUT (1 kHz) FRONT L/R	SUBWOOFER (50Hz)
Both ch, -20 dBm	- 16.0 dBm	- 21.5 dBm

1-3 MASTER VOLUME -20 dB

Input level (AUX IN)	SPEAKER OUTPUT (1 kHz) FRONT L/R	SUBWOOFER (50Hz)
Both ch, -20 dBm	+ 4.0 dBm	- 0.5 dBm

1-4 MASTER VOLUME 0 dB

Input level (AUX IN)	SPEAKER OUTPUT (1 kHz) FRONT L/R	SUBWOOFER (50Hz)
Both ch, -20 dBm	+ 24.0 dBm	+ 19.5 dBm

2. MUTE CHECK

The output condition can be selected by using SUB-MENU.
The signal is output in digital full bit without including the head margin.

2-1 MUTE OFF (Volume -20 dB)

Input level (AUX IN)	SPEAKER OUTPUT (1 kHz) FRONT L/R	SUBWOOFER (50Hz)
Both ch, -20 dBm	+ 4.0 dBm	- 0.5 dBm

2-2 SPEAKERS MUTE

Input level (AUX IN)	SPEAKER OUTPUT (1 kHz) FRONT L/R	SUBWOOFER (50Hz)
Both ch, -20 dBm	- ∞	- ∞

● ダイアグメニュー詳細

1. DSP THROUGH

サブメニューで出力レベルを選択できます。
ヘッドマージンを含まず、デジタルフルビットで出力されます。

1-1 MASTER VOLUME -90 dB**1-2 MASTER VOLUME -40 dB****1-3 MASTER VOLUME -20 dB****1-4 MASTER VOLUME 0 dB****2. MUTE CHECK**

サブメニューで出力の状態を選択できます。
ヘッドマージンを含まず、デジタルフルビットで出力されます。

2-1 MUTE OFF (Volume -20 dB)**2-2 SPEAKERS MUTE**

NX-SW1000

2-3 FRONT L/R MUTE

Input level (AUX IN)	SPEAKER OUTPUT (1 kHz) FRONT L/R	SUBWOOFER (50Hz)
Both ch, -20 dBm	- 47.0 dBm	- 0.5 dBm

2-3 FRONT L/R MUTE

2-4 SUBWOOFER MUTE

Input level (AUX IN)	SPEAKER OUTPUT (1 kHz) FRONT L/R	SUBWOOFER (50Hz)
Both ch, -20 dBm	+ 4.0 dBm	- ∞ dBm

2-4 SUBWOOFER MUTE

3. RESERVED

Not applied to this model

3. RESERVED

このモデルには適応されません

4. OUTPUT PORT CHECK

4. OUTPUT PORT CHECK

4-1 Not applied to this model

4-1 このモデルには適応されません

4-2 Not applied to this model

4-2 このモデルには適応されません

4-3 PATTERN 1

4-3 PATTERN 1

4-4 PATTERN 2

4-4 PATTERN 2

Set the output port of the microprocessor to HIGH or LOW.

マイコンの出力ポートをHIGHまたはLOWにセットします。

PATTERN 1

Pin No.	Port name	Description	Pattern 1 (High)	Pattern 2 (Low)
71	LED0	Indicator for service D300 サービス用インジケータ	Lit	Off
69	LED2	Indicator for service D302 サービス用インジケータ	Lit	Off
76	/FMT	Front L/R mute control	On	Off
4	LIM	Limiter level control	High	Low
80	SWRY	Subwoofer output relay control	On	Off
52	RYC	Power relay control	On	Off
53	/PB_INT	Interrupt for I2C communication request	High	Low
29	Y-CLK	DVR-1000 communication	High	Low

PATTERN 2

Pin No.	Port name	Description	Pattern 1 (High)	Pattern 2 (Low)
70	LED1	Indicator for service D301 サービス用インジケータ	Off	Lit
68	LED3	Indicator for service D303 サービス用インジケータ	Off	Lit
77	/SWMT	Subwoofer mute control	Off	On
79	FRY	Front L/R output relay control	Off	On
30	Y-DAT	DVR-1000 communication	Low	High

5. TEST TONE

The built-in noise generator outputs the test noise through the channels specified by the sub-menu.
The noise frequency for subwoofer is 35 to 250 Hz.
Other than that, the center frequency is 800 Hz.

5-1 All CHANNEL

A test tone is output from all the speakers.

5-2 TURN CHANGEOVER

Every time the key of the numeric "2" (sub-menu 2 key) is pushed, a test tone is output in the following order more than a speaker.

1. TEST ALL

Noise is output from all channels.
全チャンネルからノイズを出力

5. TEST TONE

内蔵のノイズ発生回路から、サブメニューで指定したチャンネルへテストトーンを出力します。
サブウーハー用のノイズ周波数は35～250 Hz、それ以外は中心周波数800 Hzとなります。

5-1 All CHANNEL

全スピーカーからテストトーンが出力されます。

5-2 TURN CHANGEOVER

数字キーの"2"キー(サブメニュー2のキー)を押す度に、以下の順序でスピーカーよりテストトーンが出力されます。

2. TEST FRONT L

Noise is output from the FRONT L channel.
FRONT Lチャンネルからノイズを出力

3. TEST FRONT R

Noise is output from the FRONT R channel.
FRONT Rチャンネルからノイズを出力

4. TEST SUBWOOFER

Noise is output from the SUBWOOFER channel.
SUBWOOFERチャンネルからノイズを出力

5-3 SUBWOOFER OUTPUT

A test tone is output from the subwoofer.

5-4 FRONT L/R 1kHz, SUBWOOFER 100Hz

A 1kHz sine wave is output at the FRONT L/R channel and a 100Hz sine wave at the SUBWOOFER channel.

5-3 SUBWOOFER OUTPUT

サブウーファーよりテストトーンが出力されます。

5-4 FRONT L/R 1kHz, SUBWOOFER 100Hz

FRONT L/Rチャンネルには1kHzのサイン波、SUBWOOFERチャンネルには100Hzのサイン波が出力されます。

6. RESERVED

Not applied to this model

6. RESERVED

このモデルには適応されません

NX-SW1000

7. DEVICE CHECK

Self-diagnostic is performed to determine whether or not communication between devices of each IC and register access are correct.

7-1 DEVICE CHECK

Displayed / 表示				Description / 状態
D300	D301	D302	D303	
● (Off)	★ (Lit)	★ (Lit)	★ (Lit)	Normal / 正常
● (Off)	● (Off)	● (Off)	★ (Flashing)	マイコン (IC13) と DIR (IC3) 間の不良
● (Off)	● (Off)	★ (Flashing)	● (Off)	マイコン (IC13) と DSP (IC1) / SDRAM (IC5) / FLASH (IC7) 間の不良

7-2 Not applied to this model

7-3 Not applied to this model

7-4 Not applied to this model

8. CPU INFORMATION

A 1 5

A: 1st digit

1: 2nd digit

5: 3rd digit

The indicator for service indicates the firmware version of the microprocessor in the binary system.

This indication is available only while the numeric key of each sub-menu on the remote controller is pressed.

* If all indicators for service are off or flashing, the firmware version is not correct.

8-1 FIRMWARE VERSION

The 1st digit of the firmware version is indicated.

Displayed / 表示 (*1)				1st digit of version バージョン1桁目
D300	D301	D302	D303	
●	●	●	★	A
●	●	★	●	B
●	●	★	★	C
●	★	●	●	D
●	★	●	★	E
	●			●
	●			●
	●			●
	●			●

*1..... ★ : Flashing / 点滅, ● : Off / 消灯

8-2 Not applied to this model

7. DEVICE CHECK

各ICのデバイス間通信及びレジスタアクセスの正否を自己診断します。

7-1 DEVICE CHECK

7-2 このモデルには適応されません

7-3 このモデルには適応されません

7-4 このモデルには適応されません

8. CPU INFORMATION

A 1 5

A: 1桁目

1: 2桁目

5: 3桁目

マイコンのファームウェアバージョンをサービス用インジケータを使って、2進数にて表示します。

ただし、各サブメニューのリモコンの数字キーを押している間のみ表示されます。

* サービス用インジケータがすべて消灯または点滅表示される場合、ファームウェアバージョンが正しくありません。

8-1 FIRMWARE VERSION

ファームウェアバージョン1桁目を表示します。

8-2 このモデルには適応されません

8-3 SERIAL VERSION BIT 4-7

The 2nd digit of the firmware version is indicated.

8-4 SERIAL VERSION BIT 0-3

The 3rd digit of the firmware version is indicated.

8-3 SERIAL VERSION BIT 4-7

ファームウェアバージョン2桁目を表示します。

8-4 SERIAL VERSION BIT 0-3

ファームウェアバージョン3桁目を表示します。

Displayed / 表示 (*1)				2nd, 3rd digit of version
D300	D301	D302	D303	バージョン2桁、3桁目
●	●	●	●	0
●	●	●	★	1
●	●	★	●	2
●	●	★	★	3
●	★	●	●	4
●	★	●	★	5
●	★	★	●	6
●	★	★	★	7
★	●	●	●	8
★	●	●	★	9

*1..... ★ : Flashing / 点滅, ● : Off / 消灯

9. EMC TEST (7ch stereo output)

Output can be adjusted in the range of master volume control for -90 to 0 dB.

10. RESERVED

Not applied to this model

11. RESERVED

Not applied to this model

12. RESERVED

Not applied to this model

13. DSP PROGRAM WRITING

Used when writing the DSP firmware.

13-1 READY FOR WRITING

Used to set to the mode ready for writing the DSP firmware.

13-2 Not applied to this model

13-3 Not applied to this model

13-4 WRITING START

Used to start writing the DSP firmware.

14 RESERVED

Not applied to this model

9. EMC TEST (7ch ステレオ出力)

出力は、マスターボリュームで-90 dB 0 dBの範囲で調節できます。

10. RESERVED

このモデルには適応されません

11. RESERVED

このモデルには適応されません

12. RESERVED

このモデルには適応されません

13. DSP PROGRAM WRITING

DSPのファームウェアを書き込むときに使用します。

13-1 READY FOR WRITING

DSPファームウェアの書き込みの待機状態にします。

13-2 このモデルには適応されません。

13-3 このモデルには適応されません。

13-4 WRITING START

DSPファームウェアの書き込みを開始します。

14 RESERVED

このモデルには適応されません

NX-SW1000



■ AMP ADJUSTMENT / アンプ調整

CONFIRMATION OF IDLING CURRENT

- Right after power is turned on, confirm that the voltage across the terminals of R79 (FRONT L ch), R80 (FRONT R ch), R71 (SUBWOOFER ch) are between 0.1 mV and 10.0 mV.

アイドリング電流の確認

- 電源投入直後、R79 (FRONT L ch)、R80 (FRONT R ch)、R71 (SUBWOOFER ch)の端子間電圧を測定し、0.1 mVから10.0 mVの間であることを確認してください。




IC DATA

IC1: D60YA003BPYP225 (DSP (1) P.C.B.)
Decoder

* No replacement part available.

サービス部品供給なし



No.	Port Name	I/O	Function	State1	State2	Signal Name	Explanation	Resistance
1	GP0[4]/EXT_INT4/AMUTEIN1	I/O	I	PU	default	DSP_MUTE3	DSP MUTE control "H" → MUTE	
2	GP0[6]/EXT_INT6	I/O	I/O/Z	PU	default	-	General purpose I/O port (no used)	13 kΩ
3	CVDD	POWER				P12V	1.2V power supply	
4	VSS	GND				DGND	Ground	
5	DVDD	POWER				P33V	3.3V power supply	
6	GP0[5]/EXT_INT5/AMUTEIN0	I/O	I/O/Z	PU	default	-	General purpose I/O port (no used)	13 kΩ
7	GP0[7]/EXT_INT7	I/O	I/O/Z	PU	default	-	General purpose I/O port (no used)	13 kΩ
8	SLKS1/SCL1	I	I		default	P33V	Outside pull up	10 kΩ
9	DVDD	POWER				P33V	3.3V power supply	
10	VSS	GND				DGND	Ground	
11	CVDD	POWER				P12V	1.2V power supply	
12	TINP1/AHCLKX0	I	I	PD	default	-	Inside pull down (timer1 input)	18 kΩ
13	TOUT1/AXR0[4]/AXR1[11]	I/O	I	PD	McASP1	-	Inside pull down (audio data input)	18 kΩ
14	CVDD	POWER				P12V	1.2V power supply	
15	VSS	GND				DGND	Ground	
16	CLKX0/ACLKX0	I/O	I/O/Z	PD	McASP0	-	Inside pull down (McASP0 transmission BCLK)	18 kΩ
17	TINP0/AXR0[3]/AXR1[12]	I/O	I	PD	McASP1	-	Inside pull down (audio data input)	18 kΩ
18	TOUT0/AXR0[2]/AXR1[13]	I/O	I	PD	McASP1	-	Inside pull down (audio data input)	18 kΩ
19	CLKR0/ACLKR0	I/O	I	PD	McASP0	DSP_BCK	DSP bit clock input	18 kΩ
20	DX0/AXR0[1]/AXR1[14]	I/O	I	PU	McASP0	-	Inside pull up (McASP0 sending and receiving data)	13 kΩ
21	FSX0/AFSX0	I/O	I/O/Z	PD	McASP0	-	Inside pull down (McASP0 transmission LRCLK)	18 kΩ
22	CVDD	POWER				P12V	1.2V power supply	
23	VSS	GND				DGND	Ground	
24	FSR0/AFSR0	I/O	I	PD	McASP0	DSP_WCK	DSP word clock input	18 kΩ
25	DVDD	POWER				P33V	3.3V power supply	
26	VSS	GND				DGND	Ground	
27	DR0/AXR0[0]/AXR1[15]	I/O	I	PU	McASP0	-	Inside pull up (McASP0 sending and receiving data)	13 kΩ
28	CLKS0/AHCLKR0	I/O	I/O/Z	PD	McASP0	-	Inside pull down (McASP0 transmission MCLK)	18 kΩ
29	CVDD	POWER				P12V	1.2V power supply	
30	VSS	GND				DGND	Ground	
31	FSX1	I/O	I	PD	McBSP1	DSP_CEN3	Chip enable "L" (McBSP1)	18 kΩ
32	DX1/AXR0[5]/AXR1[10]	I/O	I/O	PU	default	DSP_SDO3	Microcomputer I/F serial data OUT (McBSP1)	13 kΩ
33	CLKX1/AMUTE0	I/O	I/O	PD	default	DSP_SCK3	Chip enable "L" (McBSP1)	
34	VSS	GND				DGND	Ground	
35	CVDD	POWER				P12V	1.2V power supply	
36	CLKR1/AXR0[6]/AXR1[9]	I/O	I/O/Z	PD	default	-	Inside pull down (McBSP1 reception clock)	18 kΩ
37	DR1/SDA1	I	I		default	DSP_SDI3	Microcomputer I/F serial data IN (McBSP1)	
38	FSR1/AXR0[7]/AXR1[8]	I/O	I/O/Z	PD	default	-	Inside pull down (McBSP1 frame Sync)	18 kΩ
39	VSS	GND				DGND	Ground	
40	CVDD	POWER				P12V	1.2V power supply	
41	SCL0	I/O	I/O/Z			P33V	Outside pull up	10 kΩ

NX-SW1000



No.	Port Name	I/O	Function	State1	State2	Signal Name	Explanation	Resistance
42	SDA0	I/O	I/O/Z			P33V	Outside pull up	10 kΩ
43	CVDD	POWER				P12V	1.2V power supply	
44	DVDD	POWER				P33V	3.3V power supply	
45	VSS	GND				DGND	Ground	
46	CVDD	POWER				P12V	1.2V power supply	
47	DVDD	POWER				P33V	3.3V power supply	
48	VSS	GND				DGND	Ground	
49	VSS	GND				DGND	Ground	
50	CVDD	POWER				P12V	1.2V power supply	
51	CVDD	POWER				P12V	1.2V power supply	
52	VSS	GND				DGND	Ground	
53	CVDD	POWER				P12V	1.2V power supply	
54	VSS	GND				DGND	Ground	
55	DVDD	POWER				P33V	3.3V power supply	
56	ARDY	I	I	PU		P33V	Outside pull up (Asynchronous system RAM Ready input)	10 kΩ
57	CE3N	O	Z	PU		-	Inside pull up (external memory enable 3)	13 kΩ
58	DVDD	POWER				P33V	3.3V power supply	
59	VSS	GND				DGND	Ground	
60	CVDD	POWER				P12V	1.2V power supply	
61	CE2N	O	Z	PU		-	Inside pull up (external memory enable 2)	13 kΩ
62	EA2	O	O	PU		EA2	Address bus for external memory	13 kΩ
63	EA3	O	O	PU		EA3	Address bus for external memory	13 kΩ
64	EA4	O	O	PU		EA3	Address bus for external memory	13 kΩ
65	DVDD	POWER				P33V	3.3V power supply	
66	VSS	GND				DGND	Ground	
67	CVDD	POWER				P12V	1.2V power supply	
68	EA5	O	O	PU		EA5	Address bus for external memory	13 kΩ
69	EA6	O	O	PU		EA6	Address bus for external memory	13 kΩ
70	EA7	O	O	PU		EA7	Address bus for external memory	13 kΩ
71	EA8	O	O	PU		EA8	Address bus for external memory	13 kΩ
72	DVDD	POWER				P33V	3.3V power supply	
73	VSS	GND				DGND	Ground	
74	EA9	O	O	PU		EA9	Address bus for external memory	13 kΩ
75	AOEN/SDRASN/SSOEN	O	O	PU		OENSDRASN	Asynchronous system RAM OE / SDRAM RAS	13 kΩ
76	EA10	O	O	PU		EA10	Address bus for external memory	13 kΩ
77	ECLKOUT	O	O	PD		SDCLKO	Clock output for EMIF	18 kΩ
78	ECLKIN	I	I	PD		-	Clock input for EMIF	18 kΩ
79	AREN/SDCASN/SSADSN	O	O	PU		SDCASN	SDRAM CAS	13 kΩ
80	CVDD	POWER				P12V	1.2V power supply	
81	VSS	GND				DGND	Ground	
82	CLKOUT2/GP0[2]	O	O/Z	PD	GP0	-	General purpose I/O port (no used)	18 kΩ
83	AWEN/SDWEN/SSWEN	O	O	PU		WEN	Asynchronous system RAM WE / SDRAM WE	13 kΩ
84	DVDD	POWER				P33V	3.3V power supply	
85	VSS	GND				DGND	Ground	
86	EA11	O	O	PU		EA11	Address bus for external memory	13 kΩ
87	DVDD	POWER				P33V	3.3V power supply	
88	VSS	GND				DGND	Ground	
89	CVDD	POWER				P12V	1.2V power supply	
90	EA14	O	O	PU		EA14	Address bus for external memory	13 kΩ
91	EA13	O	O	PU		EA13	Address bus for external memory	13 kΩ
92	EA16	O	O	PU		EA16	Address bus for external memory	13 kΩ
93	EA12	O	O	PU		EA12	Address bus for external memory	13 kΩ
94	EA15	O	O	PU		EA15	Address bus for external memory	13 kΩ
95	EA18	O	O	PU		EA18	Address bus for external memory	13 kΩ
96	CVDD	POWER				P12V	1.2V power supply	
97	VSS	GND				DGND	Ground	
98	DVDD	POWER				P33V	3.3V power supply	
99	EA17	O	O	PU		EA17	Address bus for external memory	13 kΩ
100	EA19	O	O	PU		EA20	Address bus for external memory	13 kΩ
101	EA20	O	O	PU		EA11	Address bus for external memory	13 kΩ

No.	Port Name	I/O	Function	State1	State2	Signal Name	Explanation	Resistance
102	CE0N	O	Z	PU		CE0N	Inside pull up (external memory enable 3)	13 kΩ
103	CE1N	O	Z	PU		CE1N	Inside pull up (external memory enable 3)	13 kΩ
104	CVDD	POWER				P12V	1.2V power supply	
105	CVDD	POWER				P12V	1.2V power supply	
106	VSS	GND				DGND	Ground	
107	DVDD	POWER				P33V	3.3V power supply	
108	BE1N	O	O	PU		BE1N	Byte Enable control 1 for external memory	13 kΩ
109	EA21	O	O	PU		EA21	Address bus for external memory	13 kΩ
110	BE0N	O	O	PU		BE0N	Byte Enable control 0 for external memory	13 kΩ
111	ED13/GP1[13]	I/O	I/O/Z	PU	default	ED13	Data bus for external memory	13 kΩ
112	ED15/GP1[15]	I/O	I/O/Z	PU	default	ED15	Data bus for external memory	13 kΩ
113	ED14/GP1[14]	I/O	I/O/Z	PU	default	ED14	Data bus for external memory	13 kΩ
114	DVDD	POWER				P33V	3.3V power supply	
115	VSS	GND				DGND	Ground	
116	CVDD	POWER				P12V	1.2V power supply	
117	ED11/GP1[11]	I/O	I/O/Z	PU	default	ED11	Data bus for external memory	13 kΩ
118	ED12/GP1[12]	I/O	I/O/Z	PU	default	ED12	Data bus for external memory	13 kΩ
119	ED9/GP1[9]	I/O	I/O/Z	PU	default	ED9	Data bus for external memory	13 kΩ
120	ED10/GP1[10]	I/O	I/O/Z	PU	default	ED10	Data bus for external memory	13 kΩ
121	ED6/GP1[6]	I/O	I/O/Z	PU	default	ED6	Data bus for external memory	13 kΩ
122	ED7/GP1[7]	I/O	I/O/Z	PU	default	ED7	Data bus for external memory	13 kΩ
123	ED8/GP1[8]	I/O	I/O/Z	PU	default	ED8	Data bus for external memory	13 kΩ
124	CVDD	POWER				P12V	1.2V power supply	
125	VSS	GND				DGND	Ground	
126	DVDD	POWER				P33V	3.3V power supply	
127	ED4/GP1[4]	I/O	I/O/Z	PU	default	ED4	Data bus for external memory	13 kΩ
128	ED5/GP1[5]	I/O	I/O/Z	PU	default	ED5	Data bus for external memory	13 kΩ
129	ED3/GP1[3]	I/O	I/O/Z	PU	default	ED3	Data bus for external memory	13 kΩ
130	ED2/GP1[2]	I/O	I/O/Z	PU	default	ED2	Data bus for external memory	13 kΩ
131	ED1/GP1[1]	I/O	I/O/Z	PU	default	ED1	Data bus for external memory	13 kΩ
132	ED0/GP1[0]	I/O	I/O/Z	PU	default	ED0	Data bus for external memory	13 kΩ
133	CVDD	POWER				P12V	1.2V power supply	
134	VSS	GND				DGND	Ground	
135	HINTN/GP0[1]	I/O	I/O/Z	PU	GP0	DSP_BUSYN3	DSP BUSY signal output	13 kΩ
136	BUSREQ	O	O	PU		-	Bus request output for external memory	13 kΩ
137	HOLDAN	O	O	PU		-	Hold request output approval for external memory	13 kΩ
138	HOLDN	I	I			P33V	Outside pull up (Hold request for external memory)	4.7 kΩ
139	HHWIL/AFSR1	I/O	I	PU	McASP1	DIR_WCK	DIR word clock input (McASP1)	13 kΩ
140	HRDY/ACLKR1	I/O	I	PD	McASP1	DIR_BCK	DIR bit clock input (McASP1)	18 kΩ
141	DVDD	POWER				P33V	3.3V power supply	
142	VSS	GND				DGND	Ground	
143	HR/W/AXR0[15]/AXR1[0]	I/O	I	PU	McASP1	DIR_SDO	DIR audio data input (McASP1)	13 kΩ
144	HCNTL1/AXR0[14]/AXR1[1]	I/O	I/O/Z	PU	McASP1	-	Inside pull up (McASP1 sending and receiving data)	13 kΩ
145	HCS/AXR0[13]/AXR1[2]	I/O	O	PU	McASP1	DSP_SW	Audio data output (SW/-)	13 kΩ
146	HCNTL0/AXR0[12]/AXR1[3]	I/O	O	PU	McASP1	DSP_S	Audio data output (SL/SR)	13 kΩ
147	HD0/AXR0[11]/AXR1[4]	I/O	O	PU	McASP1	DSP_C	Audio data output (CL/CR)	13 kΩ
148	VSS	GND				DGND	Ground	
149	CVDD	POWER				P12V	1.2V power supply	
150	HDS2/AXR0[10]/AXR1[5]	I/O	O	PU	McASP1	DSP_F	Audio data output (FL/FR)	13 kΩ
151	HDS1N/AXR0[9]/AXR1[6]	I/O	I/O/Z	PU	McASP1	-	Inside pull up (McASP1 sending and receiving data)	13 kΩ
152	HD1/AXR0[8]/AXR1[7]	I/O	I	PU	McASP0	DIR_SDO	Audio data input (DIR)	13 kΩ
153	HASN/ACLKX1	I/O	O	PU	McASP1	DSP_BCK	DSP bit clock output	13 kΩ
154	HD3/AMUTE1	I/O	I	PU	default	DGND	Outside pull up (Dvice config)	1 kΩ
155	HD2/AFSX1	I/O	I	PU	McASP0	DSP_WCK	DSP word clock output	13 kΩ
156	HD4/GP0[0]	I/O	I/O	PD	both	DSP_RDYN3	Microcomputer I/F ready signal output (outside pull up)	1 kΩ
157	CVDD	POWER				P12V	1.2V power supply	
158	VSS	GND				DGND	Ground	
159	HD5/AHCLKX1	I/O	I	PU	McASP1	DIR_MCK	DIR master clock input (McASP1)	13 kΩ
160	HD8/GP0[8]	I/O	I/O/Z	PU	both	P33V	Outside pull up (Dvice config)	13 kΩ
161	HD6/AHCLKR1	I/O	I/O/Z	PU	McASP1	DGND	Out side pull up (McASP1 reception MCLK)	47 Ω

NX-SW1000

No.	Pin Name	I/O	Function	State1	State2	Signal Name	Explanation	Resistance
162	DVDD	POWER				P33V	3.3V power supply	
163	VSS	GND				DGND	Ground	
164	HD7/GP0[3]	I/O	O	PU	GP0	DSP_INT3	DSP interrupt signal output	13 kΩ
165	HD9/GP0[9]	I/O	O	PU	GP0	-	General purpose I/O port (no used)	13 kΩ
166	HD10/GP0[10]	I/O	O	PU	GP0	-	General purpose I/O port (no used)	13 kΩ
167	HD11/GP0[11]	I/O	O	PU	GP0	-	General purpose I/O port (no used)	13 kΩ
168	HD12/GP0[12]	I/O	O	PU	GP0	-	General purpose I/O port (Microphone input select signal no used)	13 kΩ
169	CVDD	POWER				P12V	1.2V power supply	
170	VSS	GND				DGND	Ground	
171	CVDD	POWER				P12V	1.2V power supply	
172	HD13/GP0[13]	I/O	I	PU	default	P33V	Outside pull up (Dvice config)	1 kΩ
173	HD14/GP0[14]	I/O	I	PU	default	DGND	Outside pull down (Dvice config)	1 kΩ
174	HD15/GP0[15]	I/O	I	PU	GP0	-	General purpose I/O port (Microphone detection select signal no used)	13 kΩ
175	NMI	I	I	PD		P33V	Outside pull up (Non maskable Interrupt)	1 kΩ
176	RESETN	I	I			DSP_ICN3	Device reset signal "L"	
177	CVDD	POWER				P12V	1.2V power supply	
178	OSCIN	I	I			DGND	Outside pull down (XTL input terminal)	2.2 Ω
179	OSCOUT	O	O			-	XTL output terminal	
180	OSCVSS	GND				-	GND for XTL (Internal connection)	
181	OSCVDD	POWER				-	Power supply for XTL (Internal connection)	
182	VSS	GND				DGND	Ground	
183	DVDD	POWER				P33V	3.3V power supply	
184	CLKOUT3	O	O	PD		-	Programmable clock output	13 kΩ
185	EMU1	I/O	I/O/Z	PU		EMU1	JTAG Emulation PIN1 (Outside pull down)	4.7 kΩ
186	EMU0	I/O	I/O/Z	PU		EMU0	JTAG Emulation PIN0 (Outside pull down)	4.7 kΩ
187	TDO	O	O	PU		TDO	JTAG data output	13 kΩ
188	DVDD	POWER				P33V	3.3V power supply	
189	VSS	GND				DGND	Ground	
190	CVDD	POWER				P12V	1.2V power supply	
191	TDI	I	I	PU		TDI	JTAG data input	13 kΩ
192	TMS	I	I	PU		TMS	JTAG mode select	13 kΩ
193	TCK	I	I	PU		TCK	JTAG clock	13 kΩ
194	VSS	GND				DGND	Ground	
195	CVDD	POWER				P12V	1.2V power supply	
196	CVDD	POWER				P12V	1.2V power supply	
197	TRSTN	I	I	PD		TRSTN	JTAG reset signal	18 kΩ
198	RSV2	-	-	-	-	-	Reserved	
199	VSS	GND				DGND	Ground	
200	RSV0	-	-	-	-	-	Reserved	
201	CVDD	POWER				P12V	1.2V power supply	
202	PLLHV	POWER				P33V	Analog power supply for PLL	
203	RSV1	-	-	-	-	DGND	Ground	
204	CLKIN	I	I	PD		XMCK	System clock input	18 kΩ
205	CLKMODE0	I	I	PU		P33V	Outside pull up (PLL clock select "H" : CLKIN)	4.7 kΩ
206	DVDD	POWER				P33V	3.3V power supply	
207	VSS	GND				DGND	Ground	
208	CVDD	POWER				P12V	1.2V power supply	

IC4: LC89057W-VF4AD-E (DSP (1) P.C.B.)
Digital Audio Interface Transceiver





NX-SW1000

Pin No.	Function Name	I/O	Detail of Function
1	RXOUT	O	Output pin of input bi-phase selection data
2	RX0	Is	Input pin of TTL-compatible digital data
3	RX1	I	Digital data input pin with built-in amplifier that supports coaxial
4	RX2	Is	Input pin of TTL-compatible digital data
5	RX3	Is	Input pin of TTL-compatible digital data
6	DGND		Digital GND
7	DVDD		Digital power supply (3.3 V)
8	RX4	Is	Input pin of TTL-compatible digital data
9	RX5	Is	TTL-compatible digital data / Validity flag input pin for modulation
10	RX6	Is	TTL-compatible digital data / User data input pin for modulation
11	DVDD		Digital power supply for PLL
12	DGND		Digital GND for PLL
13	LPF	O	PLL loop filter connection pin
14	AVDD		Analog power supply for PLL (3.3 V)
15	AGND		Analog GND for PLL
16	RMCK	O	R system clock output pin (256 fs, 512 fs, XIN, VCO)
17	RBCK	O/I	R bit clock input/output pin (64 fs)
18	DGND		Digital GND
19	DVDD		Digital power supply (3.3 V)
20	RLRCK	O/I	R LR clock input/output pin (fs)
21	RDAT A	O	Output pin of serial audio data
22	SBCK	O	S bit clock output pin (32 fs, 64 fs, 128 fs) (No connected.)
23	SLRCK	O	S LR clock output pin (fs/2, fs, 2 fs) (No connected.)
24	SDIN	Is	Input pin of serial audio data
25	DGND		Digital GND
26	DVDD		Digital power supply (3.3 V)
27	XMCK	O	Oscillation amplifier output pin
28	XOUT	O	Quartz resonator connection output pin
29	XIN	I	Quartz resonator connection, input pin of external supply clock (24.576 MHz or 12.288 MHz)
30	DVDD		Digital power supply (3.3 V)
31	DGND		Digital GND
32	EMPHA/UO/CD	I/O	Emphasis information / U data output / C data output / Chip address setting pin
33	AUDIO/VO	I/O	Non-PCM detection / V flag output / Chip address setting pin
34	CKST/PT	I/O	Output of clock switch transitional period signal / Preamble B output / Demodulation master or slave function switch pin
35	INT	I/O	Interrupt output for microprocessor (Possible to select an interrupt factor.) / Modulation or general-purpose I/O switch pin
36	RERR	O	PLL clock error, data error flag output (No connected.)
37	DO	O	Microprocessor I/F, read data output pin (3-state)
38	DI	Is	Microprocessor I/F, write data input pin
39	CE	Is	Microprocessor I/F, chip enable input pin
40	CL	Is	Microprocessor I/F, clock input pin "
41	XMODE	Is	System reset input pin
42	DGND		Digital GND
43	DVDD		Digital power supply (3.3 V)
44	PIO0	I/O	512 fs, 256 fs, 128 fs system clock input for modulation or external / General-purpose I/O input/output pin
45	PIO1	I/O	64 fs bit clock input for modulation / General-purpose I/O input/output pin
46	PIO2	I/O	fs clock input for modulation / General-purpose I/O input/output pin
47	PIO3	I/O	Serial audio data input for modulation / General-purpose I/O input/output pin
48	PIOEN	I/O	Modulation data output / General-purpose I/O enable output pin

- 1) Withstand voltage input/output: I or O = -0.3 to 3.6 V, Is = -0.3 to 5.5 V
- 2) Pins 32 and 33 are input pins for chip address setting, when pin 41 = "L".
- 3) Pin 34 is a demodulation function master or an input pin for slave setting, when pin 41 = "L".
- 4) Pin 35 is a modulation function or an input pin for general-purpose I/O function switch setting, when pin 41 = "L".
- 5) ON/OFF for all power supplies must be done at the same timing as a latch-up countermeasure.

IC13: M30626FHPFP (DSP (1) P.C.B.)
Microprocessor



NX-SW1000


Pin No.	Pin Name	Function	Name	I/O Type	Description
1	P9_6/ANEX1/SOUT4	SOUT4		O	Send Data to E-Vol
2	P9_5/ANEX0/CLK4	CLK4		O	Serial Clock for E-VOI Communication
3	P9_4/DA1/TB4IN	-			pull down
4	P9_3/DA0/TB3IN	DA0	LIM	O	Limiter Level Control
5	P9_2/TB2IN/SOUT3	SOUT3		O	Send Data to D60Y
6	P9_1/TB1IN/SIN3	SIN3		I	Receive Data from D60Y
7	P9_0/TB0IN/CLK3	CLK3		O	Serial Clock for D60Y Communication
8	BYTE	-			VSS
9	CNVSS	CNVSS		I	Normal:L, Flash Update:H
10	P8_7/XCIN	P87		O	Mute D60Y
11	P8_6/XCOUT	P86		I	D60Y Busy Detection
12	RESET	RESET		I	Reset uP
13	XOUT	XOUT		O	For Main Clock Circuit
14	VSS	-			VSS
15	XIN	XIN		I	For Main Clock Circuit
16	VCC1	-			VCC1
17	P8_5/NMI	-			pull up (VCC1)
18	P8_4/INT2/ZP	INT2		I	D60Y Interrupt
19	P8_3/INT1	INT1		I	DIR Interrupt
20	P8_2/INT0	INT0		I	Power Down Detection
21	P8_1/TA4IN/U	P8_1		O	DIR Chip Enable
22	P8_0/TA4OUT/U	P8_0		O	D60Y Chip Enable
23	P7_7/TA3IN	P7_7		O	CODEC Reset
24	P7_6/TA3OUT	P7_6		O	DIR Reset
25	P7_5/TA2IN/W	P7_5		O	D60Y Reset
26	P7_4/TA2OUT/W	P7_4		I	D60Y Ready
27	P7_3/CTS2/RTS2/TA1IN/V	P7_3		O	EEPROM Chip Enable (reserve)
28	P7_2/CLK2/TA1OUT/V	-			pull down
29	P7_1/RXD2/SCL2/TA0IN/TB5IN	SCL2		I/O	Central Unit Communication
30	P7_0/TXD2/SDA2/TA0OUT	SDA2		I/O	Central Unit Communication
31	P6_7/TXD1/SDA1	TXD1		O	Send Data to External JIG
32	P6_6/RXD1/SCL1	RXD1		I	Receive Data from External JIG
33	P6_5/CLK1	CLK1		I/O	Serial Clock for External JIG
34	P6_4/CTS1/RTS1/CTS0/CLKS1	RTS1		O	BUSY Output for External JIG
35	P6_3/TXD0/SDA0	TXD0		O	Send Data to DIR
36	P6_2/RXD0/SCL0	RXD0		I	Receive Data from DIR
37	P6_1/CLK0	CLK0		O	Serial Clock for DIR Communication
38	P6_0/CTS0/RTS0	-			pull down
39	P5_7/RDY/CLKOUT	-			pull down
40	P5_6/ALE	-			pull down
41	P5_5/HOLD	P5_5		I	pull down (/EPM for External JIG)
42	P5_4/HLDA	-			pull down
43	P5_3/BCLK	-			pull down
44	P5_2/RD	-			pull down
45	P5_1/WRH/BHE	-			pull down
46	P5_0/WRL/WR	P5_0		I	pull up (VCC2) (/CE for External JIG)
47	P4_7/CS3	-			pull down
48	P4_6/CS2	-			pull down
49	P4_5/CS1	-			pull down
50	P4_4/CS0	-			pull down

Pin No.	Pin Name	Function	Name	I/O Type	Description
51	P4_3/A19	P4_3		O	CODEC Soft Mute
52	P4_2/A18	P4_2		O	Power Relay Control
53	P4_1/A17	P4_1		O	Interrupt for I2C communication request
54	P4_0/A16	-			pull down
55	P3_7/A15	-			pull down
56	P3_6/A14	-			pull down
57	P3_5/A13	-			pull down
58	P3_4/A12	-			pull down
59	P3_3/A11	-			pull down
60	P3_2/A10	-			pull down
61	P3_1/A9	-			pull down
62	VCC2	VCC2			VCC2
63	P3_0/A8(/-/D7)	-			pull down
64	VSS	VSS			VSS
65	P2_7/AN2_7/A7(/D7/D6)	-			pull down
66	P2_6/AN2_6/A6(/D6/D5)	-			pull down
67	P2_5/AN2_5/A5(/D5/D4)	-			pull down
68	P2_4/AN2_4/A4(/D4/D3)	P2_4		O	LED3
69	P2_3/AN2_3/A3(/D3/D2)	P2_3		O	LED2
70	P2_2/AN2_2/A2(/D2/D1)	P2_2		O	LED1
71	P2_1/AN2_1/A1(/D1/D0)	P2_1		O	LED0
72	P2_0/AN2_0/A0(/D0/-)	P2_0		I	Mute Request from the Center Unit
73	P1_7/D15/INT5	P1_7	PRI	I	Protection by Electric Current Observation
74	P1_6/D14/INT4	P1_6		I	Self-mode SW
75	P1_5/D13/INT3	INT3		I	RC Signal Detection
76	P1_4/D12	P1_4	/FMT	O	Front Speaker Mute Control
77	P1_3/D11	P1_3	/SWMT	O	Sub Woofer Mute Control
78	P1_2/D10	P1_2	/SPMT	O	Speaker Mute
79	P1_1/D9	P1_1	FRY	O	Front Speaker Relay Drive
80	P1_0/D8	P1_0	SWRY	O	Sub Woofer Speaker Relay Drive
81	P0_7/AN0_7/D7	P0_7		O	E-Vol Chip Enable
82	P0_6/AN0_6/D6	-			pull down
83	P0_5/AN0_5/D5	-			pull down
84	P0_4/AN0_4/D4	-			pull down
85	P0_3/AN0_3/D3	-			pull down
86	P0_2/AN0_2/D2	-			pull down
87	P0_1/AN0_1/D1	-			pull down
88	P0_0/AN0_0/D0	-			pull down
89	P10_7/AN7/KI3	-			pull down
90	P10_6/AN6/KI2	-			pull down
91	P10_5/AN5/KI1	AN5	PLDET	I	Protection by Total Output Level
92	P10_4/AN4/KI0	AN4	THM	I	Heat Protection
93	P10_3/AN3	AN3	PRV3	I	DC Protection 3
94	P10_2/AN2	AN2	PRV2	I	DC Protection 2
95	P10_1/AN1	AN1	PRV1	I	DC Protection 1
96	AVSS	AVSS			AVSS
97	P10_0/AN0	AN0	PRD	I	DC Protection on amp output
98	VREF	VREF			VREF
99	AVCC	AVCC			VCC1
100	P9_7/ADTRG/SIN4	-			pull down

■ BLOCK DIAGRAMS


● BLOCK DIAGRAM

DVR-1000



DVR-1000

WIRING DIAGRAM



NX-SW1000

A

● BLOCK DIAGRAM


B

C

D

E

F



DVX-1000





■ PIN CONNECTION DIAGRAM

NX-SW1000

ICs

KIA7812API KIA7805API 1: OUTPUT 2: COMMON 3: INPUT	KIA7912PI 1: OUTPUT 2: INPUT 3: COMMON	KIA78L05BP 1: OUTPUT 2: COMMON 3: INPUT	LM61CIZ 3: GND 2: Vout 1: +Vs	μPC29M33T-E1-AZ 1: INPUT 2: GND 3: OUTPUT 4: GND	PQ012FZ01ZPH 1: VIN 2: VC 3: VO 4: NC 5: GND	SN74AHC1G08DCKR 1: GND 2: Input 3: Output	NJM4580E (TE2) 1: GND 2: Input 3: Output 4: Vcc 5: Input	MM74HCU04SJX SN74AHCT080PWR 1: GND 2: Input 3: Output 4: Vcc 5: Input	SN74LV245APWR 1: GND 2: Input 3: Output 4: Vcc 5: Input
AK4628VQ 1: GND 2: Input 3: Output 4: Vcc 5: Input	LC89057W-VF4D-E YAC523-VZ 1: GND 2: Input 3: Output 4: Vcc 5: Input	S29AL004D70TFI020 1: GND 2: Input 3: Output 4: Vcc 5: Input	W9816G6CH-7 1: GND 2: Input 3: Output 4: Vcc 5: Input	M30626FHPFP 1: GND 2: Input 3: Output 4: Vcc 5: Input	D60YA003BPYP225 1: GND 2: Input 3: Output 4: Vcc 5: Input	STK433-330-E 1: GND 2: Input 3: Output 4: Vcc 5: Input			


Transistors

2SC1815 Y KTA1266 Y-AT KTC3198 Y-AT 2N5401C-AT/P 2N5551C-AT/P 	2SA1770 S, T 
2SB1274 R, S 	2SC2412K Q, R, S 2SD1938 F, S, T DTA114EKA KPA104S-RTK/P KRC102S-RTK/P KRC104S-RTK/P 

FET

A diagram of a 2SK304 E transistor, which is a PNP silicon NPN transistor. The diagram shows the transistor package with three pins labeled D, G, and S. Pin D is the base, pin G is the emitter, and pin S is the collector.

Diodes


1SS355 KDS160-RTK/P MA8027 MA8051-M MA8056-M MA8068-M MA8082-M MA8270-H RB501V-40 	1SS133, 176 2SS270A 	KBP103G-01X0 RS403M-B-C-J80 	TS6P03-08
--	--	--	------------------

■ PRINTED CIRCUIT BOARDS

FOR INFORMATION ONLY (NO REPLACEMENT PARTS WILL BE AVAILABLE)

USB

(Top view)




DVR-1000

The first digit of a component indicates the component type.

1xxx : Connector	3xxx : Resistor	5xxx : Coil	7xxx : IC, Transistor, FET
2xxx : Capacitor	4xxx : SMD jumper	6xxx : Diode	9xxx : Wire jumper

USB


(Bottom view)



DVR-1000

MONO

(Top view)




The first digit of a component indicates the component type.

1xxx : Connector	3xxx : Resistor	5xxx : Coil	7xxx : IC, Transistor, FET
2xxx : Capacitor	4xxx : SMD jumper	6xxx : Diode	9xxx : Wire jumper

1101	C3	2381	D1	3362	D3	7101	A2
1102	B3	2391	A1	3363	D3	7102	A2
1103	A3	2392	A3	3364	D3	7104	A2
1104	A2	2393	D1	3365	D3	7106	C3
1105	A1	2394	D3	3366	D3	7107	C3
1107	A3	2400	C2	3367	D3	7108	C3
1108	A3	2402	D2	3368	D3	7109	C3
1109	B3	3101	A1	3369	D3	7110	C3
1110	A3	3102	A1	3370	D3	7111	B3
1151	A2	3103	A1	3371	D3	7112	B2
1152	A2	3104	A1	3372	D3	7131	A2
1153	A2	3105	C2	3373	D3	7132	A2
1301	D1	3138	C2	3374	D3	7301	D1
1302	D3	3139	C1	3375	D2	7302	A1
1303	D2	3140	C2	3376	D2	7303	A2
1304	B1	3141	C2	3381	D3	7304	D2
1305	A3	3142	C2	3391	C1	7306	D1
2101	A2	3143	C2	3392	C1	7307	C1
2103	A3	3145	C2	3393	B1	7308	C1
2105	B3	3149	C3	3394	B1	7310	D1
2107	D3	3150	C3	3401	D2	7311	B1
2126	C1	3151	C3	3402	D2	7320	C2
2130	A2	3152	C3	3403	D2	7321	D1
2138	D2	3153	B3	3404	D2	7322	D1
2141	A3	3154	B3	3405	D2		
2145	A3	3156	A3	3406	D2		
2149	C3	3157	A3	3407	D3		
2151	C1	3158	C3	3408	D3		
2153	C2	3159	C3	3409	D3		
2154	C2	3209	B1	3410	D2		
2156	C2	3301	B1	3411	D2		
2157	C2	3302	B1	3412	D2		
2159	C2	3303	B1	3413	D2		
2161	C2	3304	B1	3414	D2		
2162	C2	3305	B1	3415	D1		
2163	C2	3306	B1	3416	D2		
2165	C2	3310	D1	3417	D2		
2166	C2	3311	D1	3418	D2		
2169	C2	3312	D1	4101	A2		
2171	C2	3313	D1	4102	A2		
2174	C2	3314	D2	4115	C3		
2175	C2	3315	D2	4116	C3		
2180	B3	3316	D1	4117	C3		
2182	B3	3317	D1	4118	C3		
2184	B3	3324	D3	4119	B3		
2186	C3	3335	D2	4122	B3		
2187	C3	3336	D2	4130	B1		
2188	C3	3337	D2	4132	C1		
2189	C3	3338	D2	4302	D1		
2190	C3	3340	D1	4303	C2		
2193	C3	3341	D1	4304	C2		
2195	D3	3342	D2	4311	D1		
2196	C3	3343	D2	4312	D1		
2202	B3	3344	D2	4313	D1		
2203	B3	3345	D1	4314	D1		
2204	B3	3346	D1	4315	C1		
2210	B3	3347	D1	4316	C1		
2301	D1	3348	D2	4317	C2		
2302	A1	3349	D1	5123	A3		
2311	A2	3350	D1	5130	C2		
2315	D2	3352	C1	5300	A1		
2316	D2	3353	C1	5302	D2		
2317	D2	3354	D1	5303	D2		
2318	D2	3355	D1	5305	D1		
2319	D2	3356	C1	5308	D1		
2320	D2	3357	B1	5344	D2		
2323	D1	3361	D3	5345	D2		

The first digit of a component indicates the component type.

1xxx : Connector	3xxx : Resistor	5xxx : Coil	7xxx : IC, Transistor, FET
2xxx : Capacitor	4xxx : SMD jumper	6xxx : Diode	9xxx : Wire jumper




2102 A2	2248 A3	3166 A1	5106 B2
2104 A2	2249 B3	3167 A1	5107 B3
2106 B2	2261 A2	3168 A1	5108 A2
2108 D1	2303 B3	3171 B1	5109 C2
2111 B2	2304 A3	3172 B1	5111 A2
2112 B2	2305 A3	3173 B1	5112 A2
2113 B2	2306 A3	3174 B1	5115 C2
2116 B2	2307 A3	3175 A1	5116 C2
2117 B2	2308 A3	3176 A1	5117 C2
2118 B2	2309 A3	3177 B1	5118 C2
2119 B2	2312 A2	3178 A1	5119 C2
2120 B2	2321 C3	3181 C3	5122 B2
2121 C2	2322 C3	3182 C3	5124 C1
2122 C2	2324 D3	3183 C3	5125 C1
2123 C2	2325 D3	3184 D2	5126 C1
2127 C2	2326 D3	3185 D2	5131 C3
2131 B2	2327 D3	3186 D2	5132 C3
2132 B2	2328 D3	3191 C3	5133 C3
2133 B2	2329 D3	3192 C3	5134 D3
2134 B2	2341 D2	3193 C3	5135 D3
2135 B2	2342 D2	3194 D3	5136 D3
2136 C2	2343 D2	3195 D3	5140 A2
2139 C2	2344 D2	3196 D3	5301 A2
2142 A1	2345 D2	3325 A2	5306 C3
2146 B1	2346 D2	3326 A2	5307 C3
2150 A2	2350 B3	3328 A1	5321 A3
2152 C2	2351 B3	3358 D3	5322 A3
2155 C2	2352 B3	3359 D3	5323 A1
2158 C2	2353 B3	3377 D2	5340 B3
2164 C2	2354 B3	3378 D2	5341 B3
2167 C2	2355 B3	3379 D2	5342 A1
2168 C2	2356 B3	3380 D2	5343 A1
2172 C2	2357 B3	3398 C3	5346 B3
2173 C2	2360 B3	4103 B2	7103 A2
2181 B1	2361 B3	4104 B2	7122 A2
2183 B1	2362 B3	4105 A3	7133 B3
2185 B1	2363 C3	4106 B2	7134 B3
2191 C1	2364 A1	4107 B2	7135 B3
2194 C1	2365 A1	4123 B3	
2198 C1	2366 C3	4124 B2	
2201 B2	2395 B3	4133 A2	
2207 A1	2401 D3	4134 A2	
2208 B2	3107 B2	4135 B3	
2209 B2	3108 B2	4136 B3	
2211 A1	3110 B2	4140 B3	
2212 A1	3111 B2	4141 C2	
2213 B1	3114 A2	4142 C2	
2214 A1	3115 B2	4143 C3	
2215 A1	3117 A2	4144 C3	
2216 A1	3119 A2	4145 D3	
2221 C3	3125 A2	4146 C3	
2222 C3	3131 A2	4151 B1	
2223 C3	3132 A2	4152 B1	
2224 C3	3133 B3	4153 B1	
2225 C3	3134 B3	4154 B1	
2226 C3	3135 B3	4155 A1	
2227 D2	3136 B3	4156 A1	
2228 D3	3144 C2	4157 A1	
2229 D2	3146 C1	4158 A1	
2230 D3	3147 C1	4301 B2	
2231 D2	3148 C1	4318 B3	
2232 D3	3155 A2	4319 B3	
2241 A3	3161 A1	5101 A2	
2242 A3	3162 A2	5102 B2	
2243 A3	3163 A1	5103 C2	
2245 A3	3164 B1	5104 D1	
2247 A3	3165 B1	5105 B2	

DVR-1000

The first digit of a component indicates the component type.


1xxx : Connector	3xxx : Resistor	5xxx : Coil	7xxx : IC, Transistor, FET
2xxx : Capacitor	4xxx : SMD jumper	6xxx : Diode	9xxx : Wire jumper

AV (Top view)



1xxx : Connector	3xxx : Resistor	5xxx : Coil	7xxx : IC, Transistor, FET
2xxx : Capacitor	4xxx : SMD jumper	6xxx : Diode	9xxx : Wire jumper


(Bottom view)

[illegible]


DVR-1000

The first digit of a component indicates the component type.
1xxx : Connector 3xxx : Resistor 5xxx : Coil 7xxx : IC, Transistor, FET
2xxx : Capacitor 4xxx : SMD jumper 6xxx : Diode 9xxx : Wire jumper


FRONT (1) (Top view)




FRONT (3) (Top view)



FRONT (1) (Bottom view)



FRONT (3) (Bottom view)




DVR-1000

The first digit of a component indicates the component type.


1xxx : Connector 3xxx : Resistor 5xxx : Coil 7xxx : IC, Transistor, FET
2xxx : Capacitor 4xxx : SMD jumper 6xxx : Diode 9xxx : Wire jumper

FRONT (2) (Top view)




1200 A2
1201 A2
1202 A2
1203 A2
1204 A2
1205 A2
1206 A2
1207 A2
1208 A2
1209 A2
1210 A2
1211 A2
1212 A2
1213 A2
9200 A7
9201 A7
9202 A7
9203 A7
9204 A7
9205 A7
9206 A7
9207 A7
9208 A7
9209 A7
9210 A7
9211 A7
9212 A7
9213 A7


FRONT (4) (Top view)



FRONT (4) (Bottom view)




FRONT (2) (Bottom view)




2200 A4
2201 A4
3200 A4
3201 A4
4200 A4
4201 A4
4202 A4
4203 A4
4204 A4
4205 A4
4206 A4
4207 A4
4208 A4
4209 A4
4210 A4
4211 A4
4212 A4
4213 A4
6200 A6
6201 A6
6202 A6
6203 A6


FRONT (5) (Top view)



FRONT (5) (Bottom view)



1xxx : Connector	3xxx : Resistor	5xxx : Coil	7xxx : IC, Transistor, FET
2xxx : Capacitor	4xxx : SMD jumper	6xxx : Diode	9xxx : Wire jumper



The first digit of a component indicates the component type.

1xxx : Connector

3xxx : Resistor

5xxx : Coil

7xxx : IC, Transistor, FET

2xxx : Capacitor

4xxx : SMD jumper

6xxx : Diode

9xxx : Wire jumper


12	A1	24	A1	32	B2	43	C1
13	A1	240	A1	320	B2	432	C1
10	A2	40	A1	22	B2	322	C1
140	A1	2400	A1	3200	B2	4322	C1
100	A1	400	A1	220	B2	3222	C1
106	A1	4006	A1	2206	B2	43226	C1
109	A1	4009	A1	2209	B2	43229	C1
110	A1	4010	A1	2210	B2	43230	C1
111	A1	4011	A1	2211	B2	43231	C1
112	B1	4012	A1	2212	B2	43232	C1
114	A1	4014	A1	2214	B2	43234	C1
115	A1	4015	A1	2215	B2	43235	C1
116	A1	4016	A1	2216	B2	43236	C1
118	B1	4018	A1	2218	B2	43238	C1
119	A1	4019	A1	2219	B2	43239	C1
121	A1	4021	A1	2221	B2	43241	C1
122	A1	4022	A1	2222	B2	43242	C1
124	A1	4024	A1	2224	B2	43244	C1
125	A1	4025	A1	2225	B2	43245	C1
126	B1	4026	A1	2226	B2	43246	C1
127	A1	4027	A1	2227	B2	43247	C1
128	A1	4028	A1	2228	B2	43248	C1
130	A2	4030	A1	2230	B2	43250	C1
131	A2	4031	A1	2231	B2	43251	C1
132	A2	4032	A1	2232	B2	43252	C1
133	A2	4033	A1	2233	B2	43253	C1
134	A1	4034	A1	2234	B2	43254	C1
135	A1	4035	A1	2235	B2	43255	C1
136	A1	4036	A1	2236	B2	43256	C1
137	A1	4037	A1	2237	B2	43257	C1
138	A1	4038	A1	2238	B2	43258	C1
139	A1	4039	A1	2239	B2	43259	C1
140	A2	4040	A1	2240	B2	43260	C1
141	A2	4041	A1	2241	B2	43261	C1
142	A2	4042	A1	2242	B2	43262	C1
143	A2	4043	A1	2243	B2	43263	C1
144	A2	4044	A1	2244	B2	43264	C1
145	A2	4045	A1	2245	B2	43265	C1
146	A2	4046	A1	2246	B2	43266	C1
147	A2	4047	A1	2247	B2	43267	C1
148	A1	4048	A1	2248	B2	43268	C1
149	A1	4049	A1	2249	B2	43269	C1
150	B2	4050	A1	2250	B2	43270	C1
151	B2	4051	A1	2251	B2	43271	C1
152	B2	4052	A1	2252	B2	43272	C1
153	B2	4053	A1	2253	B2	43273	C1
154	B2	4054	A1	2254	B2	43274	C1
155	B2	4055	A1	2255	B2	43275	C1
156	B2	4056	A1	2256	B2	43276	C1
157	B2	4057	A1	2257	B2	43277	C1
158	B2	4058	A1	2258	B2	43278	C1
159	B2	4059	A1	2259	B2	43279	C1
160	B2	4060	A1	2260	B2	43280	C1
161	B2	4061	A1	2261	B2	43281	C1
162	B2	4062	A1	2262	B2	43282	C1
163	B2	4063	A1	2263	B2	43283	C1
164	B2	4064	A1	2264	B2	43284	C1
165	B2	4065	A1	2265	B2	43285	C1
166	B2	4066	A1	2266	B2	43286	C1
167	B2	4067	A1	2267	B2	43287	C1
168	B2	4068	A1	2268	B2	43288	C1
169	B2	4069	A1	2269	B2	43289	C1
170	B2	4070	A1	2270	B2	43290	C1
171	B2	4071	A1	2271	B2	43291	C1
172	B2	4072	A1	2272	B2	43292	C1
173	B2	4073	A1	2273	B2	43293	C1
174	B2	4074	A1	2274	B2	43294	C1
175	B2	4075	A1	2275	B2	43295	C1
176	B2	4076	A1	2276	B2	43296	C1
177	B2	4077	A1	2277	B2	43297	C1
178	B2	4078	A1	2278	B2	43298	C1
179	B2	4079	A1	2279	B2	43299	C1
180	B2	4080	A1	2280	B2	43300	C1
181	B2	4081	A1	2281	B2	43301	C1
182	B2	4082	A1	2282	B2	43302	C1
183	B2	4083	A1	2283	B2	43303	C1
184	B2	4084	A1	2284	B2	43304	C1
185	B2	4085	A1	2285	B2	43305	C1
186	B2	4086	A1	2286	B2	43306	C1
187	B2	4087	A1	2287	B2	43307	C1
188	B2	4088	A1	2288	B2	43308	C1
189	B2	4089	A1	2289	B2	43309	C1
190	B2	4090	A1	2290	B2	43310	C1
191	B2	4091	A1	2291	B2	43311	C1
192	B2	4092	A1	2292	B2	43312	C1
193	B2	4093	A1	2293	B2	43313	C1
194	B2	4094	A1	2294	B2	43314	C1
195	B2	4095	A1	2295	B2	43315	C1
196	B2	4096	A1	2296	B2	43316	C1
197	B2	4097	A1	2297	B2	43317	C1
198	B2	4098	A1	2298	B2	43318	C1
199	B2	4099	A1	2299	B2	43319	C1
200	B2	4100	A1	2300	B2	43320	C1

A

B

C


DVR-1000




NX-SW1000

● Semiconductor Location


Ref. No.	Location
D8	E5
D13	D5
D14	D5
D15	E4
D16	E4
D17	F4
IC1	C4
IC2	B3
IC3	C4
IC4	B3
IC5	D4
IC6	B3
IC7	D4
IC8	C5
IC9	C3
IC10	E3
IC11	E5
IC12	D5
IC13	B4
IC14	F3
IC15	E3
IC16	D5
IC17	E4
Q1	D5
Q2	D5
Q3	E4
Q4	E4
Q5	E5
Q6	E5
Q7	E5
Q8	E5




Point ① Pin 29 of IC4



Point ② Pin 13 of IC13



Point ③
CH 1 : Out of IC16
CH 2 : Collector of Q1



SYSTEM POWER SW ON SYSTEM POWER SW OFF

A

B

C

D

E


F

● Semiconductor Location

Ref. No.	Location
D1	B5
D2	B5
D3	E5
D4	B5
D5	B5
D6	D5
D7	D5
D9	E3
D10	D3
D11	D3
D12	D3
D18	B5

DSP (1)

(Side B)







DVX-1000

NX-SW1000

● Semiconductor Location

Ref. No.	Location
D301	B6
D302	B6
D303	B6
D304	B6




NX-SW1000


Semiconductor Location

Ref. No.	Location
D19	C4
D20	E4
D21	E4
D23	B3
D24	C2
D25	E3
D26	D3
D27	B4
IC10	C3
IC11	C3
IC12	C5
IC14	C4
Q26	C4
Q27	E4
Q28	E4

MAIN (2) (Side A)




MAIN (2) (Side B)




R, K, A, L models

MAIN (3) (Side A)



R, K, A, L models
MAIN (3) (W4A, W4B)

MAIN (4) (Side A)




The first digit of a component indicates the component type.

1xxx : Connector 3xxx : Resistor 5xxx : Coil 7xxx : IC, Transistor, FET
 2xxx : Capacitor 4xxx : SMD jumper 6xxx : Diode 9xxx : Wire jumper

SCHEMATIC DIAGRAMS
 FOR INFORMATION ONLY (NO REPLACEMENT PARTS WILL BE AVAILABLE)

MONO 1/2



1101 D2	2243 I3	5104 A3
1102 G1	2245 I4	5105 B4
1103 H1	2247 I4	5106 B2
1104 I6	2248 I5	5107 B5
1105 I3	2249 I9	5108 C4
1107 F5	2261 B2	5109 C1
1108 I12	3101 I3	5111 C2
1109 D1	3102 I4	5112 C2
1110 H1	3103 I4	5115 A9
1151 I5	3104 I4	5116 A9
1152 I5	3105 B10	5117 A8
1153 I5	3107 H9	5118 A8
2101 C1	3108 H9	5119 B7
2102 C1	3110 H10	5122 E5
2103 A2	3111 H10	5123 F6
2104 A2	3114 H10	5124 D3
2105 A3	3115 I12	5125 D3
2106 A3	3117 B1	5126 D3
2107 A3	3119 B1	5130 A5
2108 A4	3125 A1	5131 B13
2111 B4	3131 I10	5132 B12
2112 B4	3132 I9	5133 A12
2113 B4	3133 I8	5134 A12
2116 B3	3134 I8	5135 A10
2117 B3	3135 I7	5136 A10
2118 B3	3136 I9	5140 B2
2119 B3	3138 B10	7101 B1
2120 B3	3139 C12	7102 I13
2121 B3	3140 B10	7103 B1
2122 B3	3141 B10	7104 A1
2123 B4	3142 A9	7106 D5
2126 C5	3143 B8	7107 D4
2127 C5	3144 B7	7108 E4
2130 C4	3145 A5	7109 E3
2131 C4	3146 E3	7110 F4
2132 C5	3147 D5	7111 F3
2133 C5	3148 D4	7112 E9
2134 C5	3149 E4	7122 A1
2135 C5	3150 E3	7131 I9
2136 C5	3151 F4	7132 I9
2138 D1	3152 F3	7133 I8
2139 D1	3153 E5	7134 I7
2141 D2	3154 E5	7135 I7
2142 D2	3155 A1	F125 F12
2145 C2	3156 F6	F126 F12
2146 C3	3157 F6	F127 H10
2149 B9	3158 E4	F128 C12
2150 I13	3159 E3	F141 C6
2151 C12	3161 F4	F155 E6
2152 B9	3162 G5	F156 E6
2153 A9	3163 G5	T101 D2
2154 B9	3164 G5	T102 D2
2155 B8	3165 G5	T103 E2
2156 B8	3166 H5	T104 E2
2157 B8	3167 H5	T105 E2
2158 B8	3168 H5	T106 E2
2159 B8	3171 G2	T107 E2
2161 A8	3172 H2	T109 E2
2162 A8	3173 H2	T110 E2
2163 A8	3174 H2	T111 E2
2164 A8	3175 I2	T113 E2
2165 A7	3176 I2	T114 E2
2166 A8	3177 H2	T115 E2
2167 B8	3178 I1	T116 F2
2168 B8	3181 B12	T117 F2
2169 B7	3182 B12	T118 F2
2171 B7	3183 A11	T119 F2
2172 B7	3184 A11	T120 F2
2173 B7	3185 A11	T121 F2
2174 A4	3186 A11	T122 F2
2175 A5	3191 B13	T123 F2
2180 C3	3192 B13	T125 G1
2181 C3	3193 A12	T126 G1
2182 C3	3194 A12	T127 G1
2183 C3	3195 A10	T128 G1
2184 C3	3196 A10	T129 G1
2185 C4	3209 D13	T130 G1
2186 C6	4101 H6	T131 I1
2187 C6	4102 H6	T132 I1
2188 C6	4103 I10	T133 I1
2189 C6	4104 I8	T134 I1
2190 C6	4105 I8	T135 I1
2191 C5	4106 H10	T136 E6
2193 D2	4107 I9	T137 E6
2194 D3	4115 C6	T138 I5
2195 D5	4116 C6	T139 I5
2196 D4	4117 D6	T140 I5
2198 E3	4118 D6	T141 I5
2201 E5	4119 D6	T142 I5
2202 E6	4122 F6	T144 I6
2203 E5	4123 I9	T145 I6
2204 E5	4124 I10	T146 I6
2207 F6	4130 D13	T147 I6
2208 F6	4132 D13	T148 I4
2209 G6	4133 I9	T149 I4
2210 F5	4134 I10	T150 I4
2211 F4	4135 I7	T151 I4
2212 G5	4136 I8	T152 I4
2213 G5	4140 I8	T153 I4
2214 G5	4141 A13	T154 I5
2215 G5	4142 A13	T155 I11
2216 H5	4143 A13	T156 I11
2221 B12	4144 A13	T157 I12
2222 B13	4145 A13	T158 I12
2223 B12	4146 A13	T159 I12
2224 B12	4151 G2	T162 I5
2225 A12	4152 G2	T163 I5
2226 A12	4153 G2	T164 I5
2227 A11	4154 G2	T165 I5
2228 A12	4155 H2	T166 I5
2229 A10	4156 I2	T167 I1
2230 A10	4157 I2	
2231 A10	4158 I2	
2232 A10	5101 A1	
2241 I3	5102 G13	
2242 I3	5103 A3	

#0	PROVISION	#11	DV33	#21	WDX-8136	#31	RECEIVERS	#41	DIGITAL VIDEO	#51	SINGLE I2C	[xxx]	YHTS1000
#12	DV34	#22	WDX-8229	#32	PLAYERS	#42	ANALOG VIDEO	#52	2 I2C LINE				
#13	KHM310	#23	DLM-1D	#24	5CDC								

* Components having special characteristics are marked  and must be replaced with parts having specifications equal to those originally installed.
 * Schematic diagram is subject to change without notice.


* 印のある部品は、安全性確保部品を示しています。部品の交換が必要な場合、パーツリストに記載されている部品を使用してください。
 * 本回路図は、標準回路図です。改良のため予告なく変更することがございます。

MONO 2/2

DVR-1000

The first digit of a component indicates the component type.

- 1xxx : Connector
- 3xxx : Resistor
- 5xxx : Coil
- 7xxx : IC, Transistor, FET
- 2xxx : Capacitor
- 4xxx : SMD jumper
- 6xxx : Diode
- 9xxx : Wire jumper



1301 F13	3356 A6	T209 B12
1302 A12	3357 D7	T210 B12
1303 C13	3358 I11	T211 C12
1304 A9	3359 I12	T212 C12
1305 H9	3361 A11	T213 C12
2301 B2	3362 A11	T214 C12
2302 C2	3363 A11	T215 C12
2303 C3	3364 A10	T216 C12
2304 C3	3365 A11	T217 C12
2305 C3	3366 A10	T218 C12
2306 C3	3367 B11	T219 C12
2307 C3	3368 B11	T220 G12
2308 D3	3369 B10	T221 G12
2309 D3	3370 A10	T222 G12
2311 G3	3371 A10	T223 G12
2312 G3	3372 B11	T224 G12
2315 G5	3373 B11	T225 G12
2316 G5	3374 B11	T226 G12
2317 F8	3375 B11	T227 G12
2318 F7	3376 B11	T228 G12
2319 F5	3377 D11	T229 H12
2320 F6	3378 D11	T230 H12
2321 A6	3379 D11	T231 H12
2322 B6	3380 D11	T232 H12
2323 A2	3381 B10	T233 H12
2324 I12	3391-1 B4	T234 H12
2325 I12	3391-2 B4	T235 H12
2326 I12	3391-3 C4	T236 H12
2327 I12	3391-4 C4	T237 I12
2328 I11	3392-1 B4	T238 I12
2329 I11	3392-2 B4	T239 G12
2330-3 B4	3392-3 B4	T240 B12
2342 D11	3392-4 B4	T241 H12
2343 D11	3393-1 B6	T251 C8
2344 D12	3393-2 B6	T252 C8
2345 D12	3393-3 C6	T253 C8
2346 D12	3393-4 C6	T254 C8
2350 C7	3394-1 B6	T255 C8
2351 C7	3394-2 B6	T256 C8
2352 C7	3394-3 B6	T257 B8
2353 C7	3394-4 B6	T258 B8
2354 C7	3398 A8	T259 B8
2355 C7	3401 C10	T260 B8
2356 C7	3402 C10	T261 B8
2357 C7	3403 C10	T262 B8
2360 D8	3404 C10	T263 A8
2361 D8	3405 C11	T264 A8
2362 D8	3406 C11	T265 B8
2363 A6	3407 C11	T266 A8
2364 I9	3408 B11	T267 A8
2365 I9	3409 B11	T271 H9
2366 A7	3410 G7	T272 H9
2381 F8	3411 G7	T273 H9
2391 D6	3412 H5	T274 H9
2392 D6	3413 I5	T275 I9
2393 E6	3414 I6	
2394 E6	3415 D5	
2395 C6	3416 D5	
2400 I7	3417 E5	
2401 I11	3418 G8	
2402 G4	4301 H1	
3301-1 E1	4302 B13	
3301-2 E1	4303 H8	
3301-3 E1	4304 I8	
3301-4 E1	4311 A1	
3302-1 D1	4312 A1	
3302-2 E1	4313 B1	
3302-3 E1	4314 B1	
3302-4 E1	4315 E5	
3303-2 D1	4316 E5	
3303-3 D1	4317 E11	
3303-4 D1	4318 B9	
3304-1 D1	4319 B9	
3304-2 D1	5300 C2	
3304-3 D1	5301 F3	
3304-4 D1	5302 F5	
3305-1 D1	5303 F6	
3305-2 D1	5305 A3	
3305-3 E1	5306 A6	
3305-4 E1	5307 A6	
3306 E1	5308 F8	
3310 B2	5321 B8	
3311 B3	5322 B8	
3312 B2	5323 H8	
3313 B2	5340 D7	
3314 G7	5341 D7	
3315 H5	5342 H8	
3316 E8	5343 H8	
3317 E8	5344 C11	
3324 A11	5345 C11	
3325 H1	5346 C6	
3326 H3	7301 B1	
3328 H3	7302 E3	
3335 G4	7303 G2	
3336 H7	7304 G5	
3337 F7	7306 A2	
3338 G4	7307 A5	
3340 I11	7308 B5	
3341 H11	7310 E8	
3342 G7	7311 C5	
3343 G7	7320 I7	
3344 G7	7321 D5	
3345 H11	7322 E5	
3346 H11	T200 D13	
3347 H11	T201 A12	
3348 G7	T202 B12	
3349 H11	T203 B12	
3350 H11	T204 B12	
3352 A7	T205 B12	
3353 A5	T206 B12	
3354 A1	T207 B12	
3355 A2	T208 B12	


1	#0 PROVISION	11	DV33	21	WXD-8136	31	RECEIVERS	41	DIGITAL VIDEO	[xxx]	YHTS1000
2		12	DV34	22	WXD-8229	32	PLAYERS	42	ANALOG VIDEO		
3		13	KHM310	23	DLM-1D						
				24	5DCD						

- * Components having special characteristics are marked  and must be replaced with parts having specifications equal to those originally installed.

* Schematic diagram is subject to change without notice.
- * 印のある部品は、安全性確保部品を示しています。部品の交換が必要な場合、パーツリストに記載されている部品を使用してください。

* 本回路図は、標準回路図です。改良のため予告なく変更することがございます。

DVR-1000




1105 G5	3114 B5	5108 I2
1106 H1	3115 B10	5109 G8
1107 G1	3116 B4	5110 I2
1108 I7	3117 B7	5111 G6
1109 B13	3118 A10	5112 G7
1110-A A13	3119 A10	5114 A6
1110-B A12	3120 B3	5115 H6
1110-C A13	3121 B4	6100 A10
1111 E1	3122 B7	6103 A11
1112 F1	3123 B4	6113 B10
1113-1 C13	3124 B8	6114 B10
1113-2 C13	3125 C4	6115 G10
1114 A2	3126 C11	6116 E11
1115 B2	3127 C10	6117 E4
1116 A8	3128 C11	6118 E12
1118 I5	3129 C12	6119 E11
1119 B8	3130 C10	6120 E12
1120 B2	3131 C4	6121 H11
2102 A4	3132 C12	6122 F12
2103 A8	3133 D2	6123 G3
2104 A11	3134 D2	6124 I2
2105 A4	3135 D2	6125 H8
2106 A8	3136 D2	7100 A4
2107 A8	3137 D2	7101-1 C4
2108 H1	3138 D3	7101-1 C4
2109 A11	3139 C7	7103 C8
2110 H9	3140 C9	7104 C10
2111 A12	3141 C4	7106 C11
2112 B11	3142 D10	7107 C4
2113 A7	3143 D11	7108 C3
2114 H4	3144 D7	7109 D10
2115 A7	3145 D9	7110 D11
2116 B7	3146 D12	7111 D3
2117 H3	3147 D10	7112 E4
2118 B7	3148 D11	7113 E7
2119 B11	3149 D4	7114 F3
2120 A11	3150 A10	7115 D11
2121 I8	3151 D10	7117 G4
2122 B7	3155 D11	7118 G5
2123 C6	3156 E3	7121 H13
2124 C9	3157 E8	7122 H4
2125 C6	3158 E4	7123 H3
2126 C9	3159 B3	7124 H3
2127 C6	3164 E5	7125 H4
2128 C9	3165 E10	7126-1 I3
2129 C12	3166 E3	7126-2 I4
2130 C6	3167 E6	7128 I4
2131 C9	3168 E9	7129 G7
2132 C6	3170 E6	7130 H11
2133 C9	3171 F5	7131 H11
2134 C12	3174 F5	7132 G11
2135 C6	3175 F7	7133 I8
2136 C9	3176 F7	7115 B11
2137 I9	3178 F4	7116 B11
2138 D12	3181 F7	7117 A11
2139 D11	3182 C12	7118 A11
2140 D12	3184 F7	7119 F7
2141 E10	3185 G11	7122 F8
2142 E2	3187 G1	7124 A12
2143 I4	3188 G4	7126 A11
2144 I9	3189 G3	7127 C13
2145 E4	3191 G2	7128 D12
2146 E4	3192 G3	7129 H12
2147 D8	3193 G5	7130 E12
2148 E3	3196 H12	7131 E11
2149 I6	3197 H12	7132 E12
2150 I8	3198 H4	7133 F12
2152 E5	3200 H2	7134 F12
2153 E5	3201 H12	7135 H12
2157 E12	3202 H3	7137 A11
2158 E8	3203 H4	7146 B2
2160 E9	3204 H3	7147 B2
2161 E10	3205 I6	7148 B2
2162 E8	3206 I4	7149 B2
2163 F11	3207 I4	7150 B2
2164 F12	3208 I4	7151 B2
2165 E8	3209 I2	7152 C2
2166 F10	3210 I3	7153 C2
2167 F4	3211 I2	7154 C2
2168 E6	3212 H11	7155 C2
2169 E7	3213 I10	7156 C2
2170 F5	3221 H10	7157 C11
2172 F5	3215 I11	7305 U1
2173 F7	3216 I10	7306 E2
2175 F3	3217 I10	7307 I1
2176 F12	3218 I11	7308 E1
2177 F5	3219 I11	7309 E2
2178 G12	3220 G11	7310 E2
2179 G4	3221 H10	7311 I1
2180 F7	3222 H10	7315 I1
2181 F8	3223 H10	7316 E2
2182 G5	3224 I9	7317 H1
2183 H13	3226 I8	7318 E2
2185 H5	3403 I2	7321 I6
2186 H5	3404 G9	7322 H12
2187 H5	3405 H8	7331 G5
2189 I5	3406 H7	7332 H12
2190 I5	4100 A5	7334 F1
2191 I2	4101 A5	7336 F1
2192 I3	4103 A5	7337 F1
2193 H7	4104 B9	7338 F1
2194 H6	4106 B9	7339 F1
2195 H6	4107 H8	7430 A9
2196 H9	4108 H8	7431 A9
2197 H11	4109 I10	7432 A9
2198 H11	4110 I10	7433 A9
2199 G11	4111 H10	7440 B2
3100 A10	4112 G5	7441 B2
3102 A9	4113 G1	7442 A5
3103 A11	4114 G1	7443 A5
3105 A9	5100 A4	7444 A5
3106 A9	5101 A6	7445 A5
3107 A3	5102 D4	7446 A5
3108 A9	5103 D7	7447 A5
3110 B10	5104 F2	7448 E5
3111 A9	5105 G2	7449 E5
3112 B5	5106 G12	7450 F5
3113 B5	5107 G2	7451 F5

*** : Optional**

DVR-1000

The first digit of a component indicates the component type.

- 1xxx : Connector
- 2xxx : Capacitor
- 3xxx : Resistor
- 4xxx : SMD jumper
- 5xxx : Coil
- 6xxx : Diode
- 7xxx : IC, Transistor, FET
- 9xxx : Wire jumper



1201 A5	3332 D8	7308 E12
1202 F3	3333 D9	7310 D11
1203 I2	3334 E2	7311 D12
1204 G2	3336 D11	7315-1 E9
1205 A1	3337 D12	7315-2 D9
1208 A4	3338 D11	7316 G6
1209 B6	3339 D12	7317 F9
1210 B11	3340 D12	7319 G9
1211 E13	3341 E8	7320 H9
1212 B11	3342 E9	7321 H9
1213 B2	3343 E2	7322 I9
1214 C2	3344 E8	7323 I9
1215 B2	3345 E8	7324 I9
1216 B2	3346 E10	7325 I9
1217 B2	3347 F4	7326 B7
1218 B2	3348 F4	7327 B7
1219 B2	3349 F4	7328 I4
1220 B2	3350 E1	7329 I4
1221 B2	3351 F4	7330 I12
1222 B2	3352 F9	7331 D4
1223 B2	3353 F2	7332 D5
1224 B2	3354 E1	7333 F2
1225 B2	3355 F4	7334 F2
1226 B2	3356 F4	7335 G2
1227 B2	3357 F2	7336 G2
1228 B2	3358 F9	7337 F2
1229 B2	3359 E4	7338 G2
1230 B2	3360 E4	7339 F2
1231 B2	3361 F7	7340 G2
1232 B2	3362 F9	7341 A2
1233 B2	3363 F9	7342 A2
1234 B2	3364 F4	7343 A2
1235 B2	3365 F4	7344 D13
1236 B2	3366 F9	7345 D12
1237 B2	3367 G9	7346 B2
1238 B2	3368 G9	7347 B2
1239 B2	3369 G5	7348 B2
1240 B2	3370 G5	7349 B2
1241 B2	3371 G5	7350 B2
1242 B2	3372 G5	7351 B2
1243 B2	3373 G5	7352 B2
1244 B2	3374 G5	7353 B2
1245 B2	3375 G5	7354 B2
1246 B2	3376 G5	7355 B2
1247 B2	3377 G5	7356 B2
1248 B2	3378 G5	7357 B2
1249 B2	3379 G5	7358 B2
1250 B2	3380 G5	7359 B2
1251 B2	3381 H10	7360 B2
1252 B2	3382 H10	7361 B2
1253 B2	3383 H9	7362 B2
1254 B2	3384 H2	7363 B2
1255 B2	3385 H5	7364 B2
1256 B2	3386 H5	7365 B2
1257 B2	3387 H6	7366 B2
1258 B2	3388 H6	7367 B2
1259 B2	3389 H6	7368 B2
1260 B2	3390 I9	7369 B2
1261 B2	3391 I11	7370 B2
1262 B2	3392 I2	7371 B2
1263 B2	3393 I9	7372 B2
1264 B2	3394 I2	7373 B2
1265 B2	3395 I11	7374 B2
1266 B2	3396 I10	7375 B2
1267 B2	3397 I2	7376 B2
1268 B2	3398 I2	7377 B2
1269 B2	3399 A3	7378 B2
1270 B2	3400 I2	7379 B2
1271 B2	3401 I2	7380 B2
1272 B2	3402 I2	7381 B2
1273 B2	3403 I2	7382 B2
1274 B2	3404 B3	7383 B2
1275 B2	3405 B4	7384 B2
1276 B2	3406 B4	7385 B2
1277 B2	3407 B4	7386 B2
1278 B2	3408 B4	7387 B2
1279 B2	3409 B4	7388 B2
1280 B2	3410 B9	7389 B2
1281 B2	3411 C4	7390 B2
1282 B2	3412 C5	7391 B2
1283 B2	3413 D3	7392 B2
1284 B2	3414 D5	7393 B2
1285 B2	3415 E4	7394 B2
1286 B2	3416 F4	7395 B2
1287 B2	3417 H9	7396 B2
1288 B2	3418 B7	7397 B2
1289 B2	3419 I5	7398 B2
1290 B2	3420 B9	7399 B2
1291 B2	3421 I3	7400 B2
1292 B2	3422 I4	7401 B2
1293 B2	3423 I3	7402 B2
1294 B2	3424 I3	7403 B2
1295 B2	3425 I3	7404 B2
1296 B2	3426 I3	7405 B2
1297 B2	3427 I3	7406 B2
1298 B2	3428 I3	7407 B2
1299 B2	3429 I3	7408 B2
1300 B2	3430 I3	7409 B2
1301 B2	3431 I3	7410 B2
1302 B2	3432 I3	7411 B2
1303 B2	3433 I3	7412 B2
1304 B2	3434 I3	7413 B2
1305 B2	3435 I3	7414 B2
1306 B2	3436 I3	7415 B2
1307 B2	3437 I3	7416 B2
1308 B2	3438 I3	7417 B2
1309 B2	3439 I3	7418 B2
1310 B2	3440 I3	7419 B2
1311 B2	3441 I3	7420 B2
1312 B2	3442 I3	7421 B2
1313 B2	3443 I3	7422 B2
1314 B2	3444 I3	7423 B2
1315 B2	3445 I3	7424 B2
1316 B2	3446 I3	7425 B2
1317 B2	3447 I3	7426 B2
1318 B2	3448 I3	7427 B2
1319 B2	3449 I3	7428 B2
1320 B2	3450 I3	7429 B2
1321 B2	3451 I3	7430 B2
1322 B2	3452 I3	7431 B2
1323 B2	3453 I3	7432 B2
1324 B2	3454 I3	7433 B2
1325 B2	3455 I3	7434 B2
1326 B2	3456 I3	7435 B2
1327 B2	3457 I3	7436 B2
1328 B2	3458 I3	7437 B2
1329 B2	3459 I3	7438 B2
1330 B2	3460 I3	7439 B2
1331 B2	3461 I3	7440 B2

* Components having special characteristics are marked  and must be replaced with parts having specifications equal to those originally installed.


* Schematic diagram is subject to change without notice.

* 印のある部品は、安全性確保部品を示しています。部品の交換が必要な場合、パーツリストに記載されている部品を使用してください。

* 本回路図は、標準回路図です。改良のため予告なく変更することがございます。


1xxx : Connector	3xxx : Resistor	5xxx : Coil	7xxx : IC, Transistor, FET
2xxx : Capacitor	4xxx : SMD jumper	6xxx : Diode	9xxx : Wire jumper

FRONT (1)






63

FRONT 2/2



- 1200 A3
- 1201 A1
- 1202 A3
- 1203 A3
- 1204 B3
- 1205 C3
- 1206 C3
- 1207 D3
- 1208 D3
- 1209 E3
- 1210 E3
- 1211 E3
- 2200 C1
- 2201 E1
- 3200 B1
- 3201 C2
- 3202 C2
- 3203 C2
- 3204 D2
- 3205 D1
- 3206 D2
- 3207 E2
- 3208 E2
- 3209 E2
- 3210 B4
- 6200 C1
- 6201 C1
- 6202 D1
- 6203 E1
- 6204 B3
- 9200 E1
- 9201 B3
- 9202 C3
- 9203 C3
- 9204 E3
- 9205 E3
- 9206 E3
- 9207 D3
- 9208 B3
- 9209 D3
- 9210 E1
- 9211 E1
- 9212 E1
- 9213 E1
- 1200 A1
- 1201 A1
- 1202 A1
- 1203 A1
- 1204 A1
- 1205 A3
- 1206 A3
- 1207 A3
- 1208 A3
- 1209 C2
- 1210 C2
- 1211 D2
- 1212 E2
- 1213 E2
- 1214 E2
- 1215 B3
- 1216 C3
- 1217 C3
- 1218 D3
- 1219 D3
- 1220 E3
- 1221 E3
- 1222 E3
- 1223 E1
- 1224 E1
- 1225 A1



* Components having special characteristics are marked  and must be replaced with parts having specifications equal to those originally installed.

* Schematic diagram is subject to change without notice.

* 印のある部品は、安全性確保部品を示しています。部品の交換が必要な場合、パーツリストに記載されている部品を使用してください。


* 本回路図は、標準回路図です。改良のため予告なく変更することがございます。

The first digit of a component indicates the component type.

1xxx : Connector 3xxx : Resistor 5xxx : Coil 7xxx : IC, Transistor, FET
 2xxx : Capacitor 4xxx : SMD jumper 6xxx : Diode 9xxx : Wire jumper

HDMI 1/4

DVR-1000




HDMI 2/4

DVR-1000

The first digit of a component indicates the component type.

- 1xxx : Connector
- 3xxx : Resistor
- 5xxx : Coil
- 7xxx : IC, Transistor, FET
- 2xxx : Capacitor
- 4xxx : SMD jumper
- 6xxx : Diode
- 9xxx : Wire jumper



- 1000 G1
- 4201 D3
- 1004 I6
- 4202 F13
- 1210 F3
- 4203 A5
- 2201 E14
- 4209 I14
- 2202 G13
- 4210 G12
- 2203 G14
- 4211 G3
- 2204 G13
- 4213 A14
- 2205 H13
- 4214 E11
- 2210 B10
- 4215 E3
- 2211 D10
- 4216 E2
- 2212 D11
- 4217 E2
- 2213 D12
- 4218 G5
- 2214 D11
- 4219 G5
- 2215 E12
- 4220 C11
- 2216 D10
- 4221 C12
- 2217 A14
- 4222 C12
- 2218 E11
- 4223 H10
- 2219 I14
- 4224 I10
- 2220 E12
- 4225 H9
- 2221 G10
- 4226 I9
- 2222 G9
- 5201 H14
- 2223 C4
- 5202 C11
- 2224 E3
- 5203 D11
- 2226 F3
- 5205 F3
- 2227 I8
- 5207 E3
- 2228 H8
- 7201 A8
- 3201 G14
- 7202 E10
- 3202 A7
- 7203 A11
- 3203 H12
- 7204 A12
- 3204 H12
- 7205 B5
- 3205 H12
- 7206 C6
- 3206 H11
- 7207 H9
- 3207 I14
- 7208 I9
- 3208 I13
- 7209 G14
- 3209 I14
- 7210 D8
- 3210 E14
- F201 D2
- 3211 I14
- F202 E2
- 3212 E13
- F203 E2
- 3213 G14
- F204 E2
- 3214 G13
- F205 E2
- 3215 H13
- F206 E2
- 3216 G9
- F207 F2
- 3217 C8
- F208 E2
- 3218 B7
- F209 E3
- 3219 A6
- F210 F3
- 3220 E13
- F211 F3
- 3221 E13
- F212 F2
- 3222 B4
- F213 F2
- 3223 A8
- F214 E2
- 3224 A11
- F215 F2
- 3225 A11
- F216 G2
- 3226 C8
- F217 G2
- 3227 G3
- F218 G2
- 3228 B3
- F219 G2
- 3230 E9
- F233 G1
- 3231 E9
- F234 G5
- 3232 E9
- F235 H5
- 3233 E9
- F236 H5
- 3234 E9
- F237 H5
- 3235 E9
- F238 H5
- 3236 E9
- F239 H5
- 3237 F9
- F240 H5
- 3238 G9
- F241 H5
- 3239 G9
- F242 I5
- 3240 G9
- 3241 G9
- 3242 G9
- 3243 G9
- 3244 G9
- 3245 G9
- 3246 G9
- 3247 G9
- 3248 F9
- 3249 F9
- 3250 F9
- 3251 F9
- 3252 F9
- 3253 F9
- 3254 F9
- 3255 F9
- 3256 F9
- 3257 F9
- 3258 I13
- 3259 I13
- 3260 D14
- 3263 A11
- 3264 A12
- 3269 A7
- 3270 A7
- 3271 A7
- 3272 A7
- 3273 B6
- 3274 A5
- 3276 C6
- 3277 A6
- 3278 B7
- 3279 A5
- 3280 H8
- 3281 C4
- 3282 D2
- 3283 D2
- 3284 G3
- 3285 G3
- 3288 E14
- 3290 I8
- 3291 B11
- 3292 B12
- 3293 B12
- 3294 E12
- 3295 E12
- 3296 E12
- 3297 E12
- 3298 F12
- 3299 F12
- 4200 D3

Ref Des	1210	7202	3203 3205	3204 3206
Variant				
DV6001	F 1A	ADV7320	2K7	330R
	1206 0R	ADV7320	2K7	330R

* Components having special characteristics are marked $\triangle$ and must be replaced with parts having specifications equal to those originally installed.
* Schematic diagram is subject to change without notice.

* $\triangle$ 印のある部品は、安全性確保部品を示しています。部品の交換が必要な場合、パーツリストに記載されている部品を使用してください。
* 本回路図は、標準回路図です。改良のため予告なく変更することがございます。

The first digit of a component indicates the component type.

1xxx : Connector

3xxx : Resistor

5xxx : Coil

7xxx : IC, Transistor, FET

2xxx : Capacitor


4xxx : SMD jumper

6xxx : Diode

9xxx : Wire jumper

HDMI 3/4

DVR-1000



Ref Des	1003	1301	1302	1310	2302 2311	2340 2341	2302 2309	2330 2331	2303 2310	2304 2311	2300 2305	2311 2312	2348 2349	2322 2323
Variant	NOT USED	USED	USED	F 2A	22p	22p	150R	1K2	1K2	1K2	1K2	4u7	2u2	USED
DV6001	USED	NOT USED	JAPAN VER	1206 0R	22p	22p	1K2	1K2	1K2	1K2	4u7	2u2	USED	NOT USED


- * Components having special characteristics are marked $\triangle$ and must be replaced with parts having specifications equal to those originally installed.
- * Schematic diagram is subject to change without notice.

* △印のある部品は、安全性確保部品を示しています。部品の交換が必要な場合、パーツリストに記載されている部品を使用してください。

* 本回路図は、標準回路図です。改良のため予告なく変更することがございます。

DVR-1000

1xxx : Connector	3xxx : Resistor	5xxx : Coil	7xxx : IC, Transistor, FET
2xxx : Capacitor	4xxx : SMD jumper	6xxx : Diode	9xxx : Wire jumper




* △印のある部品は、安全性確保部品を示しています。部品の交換が必要な場合、パーツリストに記載されている部品を使用してください。

* 本回路図は、標準回路図です。改良のため予告なく変更することがございます。

The first digit of a component indicates the component type.

1xxx : Connector 3xxx : Resistor 5xxx : Coil 7xxx : IC, Transistor, FET
2xxx : Capacitor 4xxx : SMD jumper 6xxx : Diode 9xxx : Wire jumper

USB




* Components having special characteristics are marked $\triangle$ and must be replaced with parts having specifications equal to those originally installed.
* Schematic diagram is subject to change without notice.

* $\triangle$ 印のある部品は、安全性確保部品を示しています。部品の交換が必要な場合、パーツリストに記載されている部品を使用してください。
* 本回路図は、標準回路図です。改良のため予告なく変更することがございます。

DVX-1000

DVR-1000

POWER SUPPLY UNIT




* Components having special characteristics are marked  and must be replaced with parts having specifications equal to those originally installed.
* Schematic diagram is subject to change without notice.


* 印のある部品は、安全性確保部品を示しています。部品の交換が必要な場合、パーツリストに記載されている部品を使用してください。
* 本回路図は、標準回路図です。改良のため予告なく変更することがございます。

■ SCHEMATIC DIAGRAMS DSP 1/2


NX-SW1000




IC13: M30626FHPFP
Single-chip 16-bit CMOS microprocessor




IC4: LC89057W-VF4AD-E
Digital audio interface transceiver




IC5: W9816G6CH-7
512K x 2 banks x 16 bits SDRAM




IC7: S29AL004D70TF020
4M bit flash memory




IC1: D60YA003BYP225
Decoder




IC10: AK4628VQ
192 kHz 24-bit 8-channel CODEC




IC3: SN74AHC1G08DCKR
Single 2 input AND




IC2: MM74HC04SJX
Hex inverters




IC6, 9: SN74AHC08PWR
Quad 2 input AND




IC8: SN74LV245APWR
Octal 3-state bus transceivers




IC11: PQ012F201ZPH
Regulator




IC14, 15: NJM4580E
Dual operational amplifier




Point ① Pin 29 of IC4



Point ② Pin 13 of IC13




Point ③
CH 1 : Out of IC16
CH 2 : Collector of Q1



* All voltages are measured with a 10MΩV DC electronic volt meter.
* Components having special characteristics are marked Δ, and must be replaced with parts having specifications equal to those originally installed.
* Schematic diagram is subject to change without notice.

* 電圧は、内部抵抗10MΩの電圧計で測定したものです。
* Δ印のある部品は、安全確保部品を示しています。部品の交換が必要な場合、パーツリストに記載されている部品を使用してください。
* 本回路図は、標準回路図です。改良のため予告なく変更することがございます。

REGULATOR




RESISTOR	
REMARKS	PARTS NAME
NO MARK	CARBON FILM RESISTOR (P=5)
	CARBON FILM RESISTOR (P=10)
	METAL OXIDE FILM RESISTOR
	METAL FILM RESISTOR
	METAL PLATE RESISTOR
	FIRE PROOF CARBON FILM RESISTOR
	CEMENT MOLDED RESISTOR
	SEMI VARIABLE RESISTOR
	CHIP RESISTOR

CAPACITOR		
REMARKS	PARTS NAME	
NO MARK	ELECTROLYTIC CAPACITOR	H
⊗	TANTALUM CAPACITOR	
NO MARK	CERAMIC CAPACITOR	H
●	CERAMIC TUBULAR CAPACITOR	
⊙	POLYESTER FILM CAPACITOR	
○	POLYSTYRENE FILM CAPACITOR	
⌒	MICA CAPACITOR	
Ⓟ	POLYPROPYLENE FILM CAPACITOR	
⊕	SEMICONDUCTIVE CERAMIC CAPACITOR	


Page 73 A4
to MAIN (1)_CB1

NOTICE (model)

(J)..... JAPAN
(U)..... U. S. A
(C)..... CANADA
(R)..... GENERAL
(T)..... CHINA
(K)..... KOREA
(A)..... AUSTRALIA
(B)..... BRITISH
(G)..... STANDARD
(L)..... SINGAPORE
(E)..... SOUTH EUROPE
(V)..... TAIWAN
(F)..... RUSSIAN




DSP (2)

SYSTEM
CONNECTORPage 71 L4
to DSP (1)_W7

Page 71 L5
to DSP (1)_W8

Page 71 J1
to DSP (1)_W2

DSP (3)

Page 71 J2
to DSP (1)_W3

Page 71 [L2]
to DSP (1)_W4

Page 72 [L4]
to DSP (1)_W9

NOTICE (model)
(J)..... JAPAN
(U)..... U.S.A
(C)..... CANADA
(R)..... GENERAL
(T)..... CHINA
(K)..... KOREA
(A)..... AUSTRALIA
(B)..... BRITISH
(G)..... STANDARD
(L)..... SINGAPORE
(E)..... SOUTH EUROPE
(V)..... TAIWAN
(F)..... RUSSIAN


RESISTOR	
REMARKS	PARTS NAME
NO MARK	CARBON FILM RESISTOR (P=5)
□	TANTALUM CAPACITOR
□	CARBON FILM RESISTOR (P=10)
△	METAL OXIDE FILM RESISTOR
△	METAL FILM RESISTOR
□	METAL PLATE RESISTOR
□	FIRE PROOF CARBON FILM RESISTOR
□	CEMENT MOLDED RESISTOR
□	SEMI VARIABLE RESISTOR
■	CHIP RESISTOR

CAPACITOR	
REMARKS	PARTS NAME
NO MARK	ELECTROLYTIC CAPACITOR
□	TANTALUM CAPACITOR
□	CERAMIC CAPACITOR
□	CERAMIC TUBULAR CAPACITOR
□	POLYESTER FILM CAPACITOR
□	POLYSTYRENE FILM CAPACITOR
□	MICA CAPACITOR
□	POLYPROPYLENE FILM CAPACITOR
□	SEMICONDUCTIVE CERAMIC CAPACITOR
□	POLYPHENYLENE SULFIDE FILM CAPACITOR


Interchangeable Parts at Manufacture-Stage

Mark	Reference Parts Number	Parts Name
k1	D1-4, 6, 7, 11-14, 16	HSS104
		1SS133
		1SS176
k2	IC7	STK433-330-E
		STK433-330Y-E
k3	Q7, 8	2SB1274(R/S)
		2SB1565(E/F)
		KT41046-Y-U/P
k4		
k5		
k6	Q21-22	KBA1045-RTK/P
		DTA144EKA
k7	Q23-24, 30-31	KRC102S-RTK/P
		OTC114EKA
k8	Q25	2SC1815(Y)
		KTC319B Y-AT

IC7: STK433-330-E
3-channel AF power amplifier, stand-by circuit built-in



IC1-4 : NJM4580E
Dual operational amplifier



* All voltages are measured with a 10MΩ/V DC electronic volt meter.
* Components having special characteristics are marked △, and must be replaced with parts having specifications equal to those originally installed.
* Schematic diagram is subject to change without notice.

* 電圧は、内部抵抗10MΩの電圧計で測定したものです。
* △印のある部品は、安全性確保部品を示しています。部品の交換が必要な場合、パーツリストに記載されている部品を使用してください。
* 本回路図は、標準回路図です。改良のため予告なく変更することがございます。

1

2

3

4

5

6


7

8


9

10

NX-SW1000



Page 73 [K1] to MAIN (1)_W1A



SPEAKERS

RESISTOR	
REMARKS	PARTS NAME
NO MARK	CARBON FILM RESISTOR (P=5)
	CARBON FILM RESISTOR (P=10)
	METAL OXIDE FILM RESISTOR
	METAL FILM RESISTOR
	METAL PLATE RESISTOR
	FIRE PROOF CARBON FILM RESISTOR
	CEMENT MOLDED RESISTOR
	SEMI VARIABLE RESISTOR
	CHIP RESISTOR


CAPACITOR	
REMARKS	PARTS NAME
NO MARK	ELECTROLYTIC CAPACITOR
	TANTALUM CAPACITOR
NO MARK	CERAMIC CAPACITOR
	CERAMIC TUBULAR CAPACITOR
	POLYESTER FILM CAPACITOR
	POLYSTYRENE FILM CAPACITOR
	MICA CAPACITOR
	POLYPROPYLENE FILM CAPACITOR
	SEMICONDUCTIVE CERAMIC CAPACITOR
	POLYPHENYLENE SULFIDE FILM CAPACITOR

Interchangeable Parts at Manufacture-Stage

Mark	Reference Parts Number	Parts Name
&10	D24	TS6P03G-08-X0
&11	D23	KBP103G-01X0
		RS103
&12	D27	RS403M-B-C-J80
		TS4B03G-07 X0
&13	D20, 21	1SS355
		MA111
&14	Q27	KRC104S-RTK/P
		DTC144EKA
&15	Q28	2SC2412K(Q/R/S)
		KTC3875S-Y, SR-RTK/P
		2SD601ARL/AQL(G/R/S)
&16	D19	HSS104
		1SS133
		1SS176
&17	Q26	2SC1815(Y)
		KTC319B Y-AT
&18	RY3	D61201-01M1-II
		ALKS321
		G5PA-1
		SDT-S-112LMR

Destination Part List				
sXX	LOC	J	RKAL	G.F
s1	F1	WB76060 6.3A250V	WB76060 6.3A250V	VV07170 3.15A250V
s2	SW6	X	WC90670 SDKPA40300	X
s3	CB10	X	V937790 B4P75-VH	X
s4	TE2	X	WB78260 R-30190(26)	X
s5	W4	X	WN51050	X
s7	TE1	LTS0410-0015FM	LTS0410-0016FM	LTS0410-0016FM
s8	PN8	X	V963750	X
s9	R157	X	RD35715 15K	X
s10	D31	X	VU99960 MA8270-H	X

R, K, A, L models




NOTICE (model)
(J)..... JAPAN
(U)..... U.S. A
(C)..... CANADA
(R)..... GENERAL
(T)..... CHINA
(K)..... KOREA
(A)..... AUSTRALIA
(B)..... BRITISH
(G)..... STANDARD
(L)..... SINGAPORE
(E)..... SOUTH EUROPE
(V)..... TAIWAN
(F)..... RUSSIAN

J, G, F models



IC14: LM61CIZ
Temperature sensor



* All voltages are measured with a 10MΩ/DC electronic volt meter.
* Components having special characteristics are marked Δ, and must be replaced with parts having specifications equal to those originally installed.
* Schematic diagram is subject to change without notice.

* 電圧は、内部抵抗10MΩの電圧計で測定したものです。
* Δ印のある部品は、安全性確保部品を示しています。部品の交換が必要な場合、パーツリストに記載されている部品を使用してください。
* 本回路図は、標準回路図です。改良のため予告なく変更することがございます。

■ REPLACEMENT PARTS LIST

● ELECTRICAL COMPONENT PARTS

WARNING

- Components having special characteristics are marked $\triangle$ and must be replaced with parts having specifications equal to those originally installed.
- The chip resistor is not supplied as a replacement part.
* When a chip resistor is necessary, use the following part.
AAX60720: CHIP RESISTOR SAMPLE BOOK
- $\triangle$ 印のある部分は、安全確保部品を示しています。部品の交換が必要な場合、パーツリストに記載されている部品を使用してください。
- チップ抵抗はサービス部品として供給しません。
※ チップ抵抗が必要な場合は、下記の部品をご利用ください。
AAX60720: CHIP RESISTOR SAMPLE BOOK
- 部品価格ランクは、予告なく変更することがあります。

ABBREVIATIONS IN THIS LIST ARE AS FOLLOWS :

C.A.EL.CHP	: CHIP ALUMI. ELECTROLYTIC CAP	L.EMIT	: LIGHT EMITTING MODULE
C.CE	: CERAMIC CAP	LED.DSPLY	: LED DISPLAY
C.CE.ARRAY	: CERAMIC CAP ARRAY	LED.INFRD	: LED, INFRARED
C.CE.CHP	: CHIP CERAMIC CAP	MODUL.RF	: MODULATOR, RF
C.CE.ML	: MULTILAYER CERAMIC CAP	PHOT.CPL	: PHOTO COUPLER
C.CE.M.CHP	: CHIP MULTILAYER CERAMIC CAP	PHOT.INTR	: PHOTO INTERRUPTER
C.CE.SAFTY	: RECOGNIZED CERAMIC CAP	PHOT.RFLCT	: PHOTO REFLECTOR
C.CE.TUBLR	: CERAMIC TUBULAR CAP	PIN.TEST	: PIN, TEST POINT
C.CE.SMI	: SEMI CONDUCTIVE CERAMIC CAP	PLST.RIVET	: PLASTIC RIVET
C.EL	: ELECTROLYTIC CAP	R.ARRAY	: RESISTOR ARRAY
C.MICA	: MICA CAP	R.CAR	: CARBON RESISTOR
C.ML.FLM	: MULTILAYER FILM CAP	R.CAR.CHP	: CHIP RESISTOR
C.MP	: METALLIZED PAPER CAP	R.CAR.FP	: FLAME PROOF CARBON RESISTOR
C.MYLAR	: MYLAR FILM CAP	R.CEMENT	: CEMENT RESISTOR
C.MYLAR.ML	: MULTILAYER MYLAR FILM CAP	R.FUS	: FUSABLE RESISTOR
C.PAPER	: PAPER CAPACITOR	R.MTL.CHP	: CHIP METAL FILM RESISTOR
C.PLS	: POLYSTYRENE FILM CAP	R.MTL.FLM	: METAL FILM RESISTOR
C.POL	: POLYESTER FILM CAP	R.MTL.OXD	: METAL OXIDE FILM RESISTOR
C.POLY	: POLYETHYLENE FILM CAP	R.MTL.PLAT	: METAL PLATE RESISTOR
C.PP	: POLYPROPYLENE FILM CAP	RSNR.CE	: CERAMIC RESONATOR
C.TNTL	: TANTALUM CAP	RSNR.CRYS	: CRYSTAL RESONATOR
C.TNTL.CHP	: CHIP TANTALUM CAP	R.TW.CEM	: TWIN CEMENT FIXED RESISTOR
C.TRIM	: TRIMMER CAP	SCR.BND.HD	: BIND HEAD B-TITE SCREW
CN	: CONNECTOR	SCR.BW.HD	: BW HEAD TAPPING SCREW
CN.BS.PIN	: CONNECTOR, BASE PIN	SCR.CUP	: CUP TITE SCREW
CN.CANNON	: CONNECTOR, CANNON	SCR.TERM	: SCREW TERMINAL
CN.DIN	: CONNECTOR, DIN	SCR.TR	: SCREW, TRANSISTOR
CN.FLAT	: CONNECTOR, FLAT CABLE	SUPRT.PCB	: SUPPORT, P.C.B.
CN.POST	: CONNECTOR, BASE POST	SURG.PRTCT	: SURGE PROTECTOR
COIL.MX.AM	: COIL, AM MIX	SW.TACT	: TACT SWITCH
COIL.AT.FM	: COIL, FM ANTENNA	SW.LEAF	: LEAF SWITCH
COIL.DT.FM	: COIL, FM DETECT	SW.LEVER	: LEVER SWITCH
COIL.MX.FM	: COIL, FM MIX	SW.MICRO	: MICRO SWITCH
COIL.OUTPT	: OUTPUT COIL	SW.PUSH	: PUSH SWITCH
DIOD.ARRAY	: DIODE ARRAY	SW.RT.ENC	: ROTARY ENCODER
DIODE.BRG	: DIODE BRIDGE	SW.RT.MTR	: ROTARY SWITCH WITH MOTOR
DIODE.CHP	: CHIP DIODE	SW.RT	: ROTARY SWITCH
DIODE.VAR	: VARACTOR DIODE	SW.SLIDE	: SLIDE SWITCH
DIOD.Z.CHP	: CHIP ZENER DIODE	TERM.SP	: SPEAKER TERMINAL
DIODE.ZENR	: ZENER DIODE	TERM.WRAP	: WRAPPING TERMINAL
DSCR.CE	: CERAMIC DISCRIMINATOR	THRMST.CHP	: CHIP THERMISTOR
FER.BEAD	: FERRITE BEADS	TR.CHP	: CHIP TRANSISTOR
FER.CORE	: FERRITE CORE	TR.DGT	: DIGITAL TRANSISTOR
FET.CHP	: CHIP FET	TR.DGT.CHP	: CHIP DIGITAL TRANSISTOR
FL.DSPLY	: FLUORESCENT DISPLAY	TRANS	: TRANSFORMER
FLTR.CE	: CERAMIC FILTER	TRANS.PULS	: PULSE TRANSFORMER
FLTR.COMB	: COMB FILTER MODULE	TRANS.PWR	: POWER TRANSFORMER ASS'y
FLTR.LC.RF	: LC FILTER, EMI	TUNER.AM	: TUNER PACK, AM
GND.MTL	: GROUND PLATE	TUNER.FM	: TUNER PACK, FM
GND.TERM	: GROUND TERMINAL	TUNER.PK	: FRONT-END TUNER PACK
HOLDER.FUS	: FUSE HOLDER	VR	: ROTARY POTENTIOMETER
IC.PRTCT	: IC PROTECTOR	VR.MTR	: POTENTIOMETER WITH MOTOR
JUMPER.CN	: JUMPER CONNECTOR	VR.SW	: POTENTIOMETER WITH ROTARY SW
JUMPER.TST	: JUMPER, TEST POINT	VR.SLIDE	: SLIDE POTENTIOMETER
L.DTCT	: LIGHT DETECTING MODULE	VR.TRIM	: TRIMMER POTENTIOMETER

NX-SW1000

P.C.B. DSP

Ref No.	Part No.	Description	Remarks	Markets	部品名	ランク
*	WM892700	P.C.B.	DSP		P C B D S P	
CB200	VQ044400	CN.BS.PIN	9P		F F Cコネクタ	01
CB201	VB858400	CN.BS.PIN	5P		ベースピン	01
CB202	VB858500	CN.BS.PIN	6P		ベースピン	01
CB203	VB858800	CN.BS.PIN	9P		ベースピン	01
CB304	VB858700	CN.BS.PIN	8P		ベースピン	01
C1	UR837100	C.EL	10uF 16V		ケミコン	01
C2-12	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C13	US061220	C.CE.CHP	22pF 50V B		チップセラコン	01
C14-18	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C19	UR837100	C.EL	10uF 16V		ケミコン	01
C20	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C21	US035100	C.CE.CHP	0.1uF 16V B		チップセラコン	01
C22	UR847220	C.EL	22uF 25V		ケミコン	01
C23	UR818100	C.EL	100uF 6.3V		ケミコン	01
C24	US061220	C.CE.CHP	22pF 50V B		チップセラコン	01
C25-29	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C30	UU267100	C.EL	10uF 50V		ケミコン FW	01
C31	US126100	C.CE.CHP	1uF 10V		チップセラコン	01
C32-35	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C36	US035100	C.CE.CHP	0.1uF 16V B		チップセラコン	01
C37-38	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C39	UR837100	C.EL	10uF 16V		ケミコン	01
C40-48	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C49	US061100	C.CE.CHP	10pF 50V B		チップセラコン	01
C50	UR838100	C.EL	100uF 16V		ケミコン	01
C51	UA654680	C.MYLAR	0.068uF 50V J		マイラーコン	02
C52	UA653100	C.MYLAR	1000pF 50V J		マイラーコン	03
C53	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C54	UR837100	C.EL	10uF 16V		ケミコン	01
C55-61	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C62	US063100	C.CE.CHP	1000pF 50V B		チップセラコン	01
C63-64	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C65	UR837100	C.EL	10uF 16V		ケミコン	01
C66-70	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C71-72	US061180	C.CE.CHP	18pF 50V B		チップセラコン	01
C73	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C74	UR837100	C.EL	10uF 16V		ケミコン	01
C75-77	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C78	US035100	C.CE.CHP	0.1uF 16V B		チップセラコン	01
C79-87	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C88	US063100	C.CE.CHP	1000pF 50V B		チップセラコン	01
C89	UR837100	C.EL	10uF 16V		ケミコン	01
C90-91	US035100	C.CE.CHP	0.1uF 16V B		チップセラコン	01
C94-95	UR837100	C.EL	10uF 16V		ケミコン	01
C96	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C97	UR818470	C.EL	470uF 6.3V		ケミコン	01
C98	UR818100	C.EL	100uF 6.3V		ケミコン	01
C99	US035100	C.CE.CHP	0.1uF 16V B		チップセラコン	01
C100	UR837100	C.EL	10uF 16V		ケミコン	01
C101	UR818470	C.EL	470uF 6.3V		ケミコン	01
C102	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C103	US065100	C.CE.CHP	0.1uF 50V B		チップセラコン	01
C104	UU238330	C.EL	330uF 16V		ケミコン FW	01

* New Parts (新規部品)

NX-SW1000

P.C.B. DSP

Ref No.	Part No.	Description	Remarks	Markets	部品名	ランク
C105	UR818100	C.EL	100uF 6.3V		ケミコン	01
C106-111	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C112	US035100	C.CE.CHP	0.1uF 16V B		チップセラコン	01
C113	UU266220	C.EL	2.2uF 50V		ケミコン FW	01
C114	US061330	C.CE.CHP	33pF 50V B		チップセラコン	01
C115-117	UU267100	C.EL	10uF 50V		ケミコン FW	01
C118-119	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C120	US064150	C.CE.CHP	0.015uF 50V B		チップセラコン	01
C121-123	UA653270	C.MYLAR	2700pF 50V J		マイラーコン	01
C124-126	VQ462600	C.MYLAR	220pF 50V		マイラーコン	01
C127-130	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C131-133	UU267100	C.EL	10uF 50V		ケミコン FW	01
C134-137	US061330	C.CE.CHP	33pF 50V B		チップセラコン	01
C138-139	UU248220	C.EL	220uF 25V		ケミコン	01
C140	UR847100	C.EL	10uF 25V		ケミコン	01
C141	US065100	C.CE.CHP	0.1uF 50V B		チップセラコン	01
C142	UR847470	C.EL	47uF 25V		ケミコン	01
C143-144	US062100	C.CE.CHP	100pF 50V B		チップセラコン	01
C145	UR866100	C.EL	1uF 50V		ケミコン	01
C146-147	US062100	C.CE.CHP	100pF 50V B		チップセラコン	01
C148	US065100	C.CE.CHP	0.1uF 50V B		チップセラコン	01
C149-150	US062100	C.CE.CHP	100pF 50V B		チップセラコン	01
C151	UR848470	C.EL	470uF 25V		ケミコン	01
C152-153	US035100	C.CE.CHP	0.1uF 16V B		チップセラコン	01
C154	US062100	C.CE.CHP	100pF 50V B		チップセラコン	01
C155-156	US035100	C.CE.CHP	0.1uF 16V B		チップセラコン	01
C157	US062100	C.CE.CHP	100pF 50V B		チップセラコン	01
C159-160	US035100	C.CE.CHP	0.1uF 16V B		チップセラコン	01
C161	US062100	C.CE.CHP	100pF 50V B		チップセラコン	01
C162-166	US035100	C.CE.CHP	0.1uF 16V B		チップセラコン	01
C169-170	UU267100	C.EL	10uF 50V		ケミコン FW	01
C171-172	UU267470	C.EL	47uF 50V		ケミコン FW	01
C173-175	US062100	C.CE.CHP	100pF 50V B		チップセラコン	01
C176-177	UU238100	C.EL	100uF 16V		ケミコン	01
C178-179	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C180-181	UU267100	C.EL	10uF 50V		ケミコン FW	01
C182-184	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C185	UU267330	C.EL	33uF 50V		ケミコン FW	01
C186	UU267100	C.EL	10uF 50V		ケミコン FW	01
C187-191	UU267330	C.EL	33uF 50V		ケミコン FW	01
C192	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C193	UU267330	C.EL	33uF 50V		ケミコン FW	01
C194-196	UU267100	C.EL	10uF 50V		ケミコン FW	01
C197	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C198	US035100	C.CE.CHP	0.1uF 16V B		チップセラコン	01
C200-202	US035100	C.CE.CHP	0.1uF 16V B		チップセラコン	01
C203	US062470	C.CE.CHP	470pF 50V B		チップセラコン	01
C204-205	US035100	C.CE.CHP	0.1uF 16V B		チップセラコン	01
C301	UM397100	C.EL	10uF 16V		ケミコン	01
C302-303	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
D1-2	VU992600	DIODE.ZENR	MA8051-M 5.1V		ツェナーダイオード	01
D3	VT332900	DIODE	1SS355		ダイオード	01
D4-5	VU992600	DIODE.ZENR	MA8051-M 5.1V		ツェナーダイオード	01
D6-8	VT332900	DIODE	1SS355		ダイオード	01

* New Parts (新規部品)

NX-SW1000

P.C.B. DSP & MAIN

Ref No.	Part No.	Description	Remarks	Markets	部品名	ランク
D9-12	VV220700	DIODE.SHOT	RB501V-40		ショットキーダイオード	01
D13	VU990100	DIODE.ZENR	MA8027 2.7V		ツェナーダイオード	01
D14	VT332900	DIODE	1SS355		ダイオード	01
D15-16	VU993800	DIODE.ZENR	MA8068-M 6.8V		ツェナーダイオード	01
D17	VU993000	DIODE.ZENR	MA8056-M 5.6V		ツェナーダイオード	01
D18	VU992600	DIODE.ZENR	MA8051-M 5.1V		ツェナーダイオード	01
* D300-303	WM880900	LED.CHP	RED		チップLED	
IC2	XY070A00	IC	MM74HCU04SJX INVER		ロジックIC	01
IC3	X3833A00	IC	SN74AHC1G08DCKR		ロジックIC	01
IC4	X5444A00	IC	LC89057W-VF4D-E		IC	07
IC5	X2590B00	IC	W9816G6CH-7 SDRAM		メモリIC 16M	06
IC6	X3824A00	IC	SN74AHCT08PWR		ロジックIC	01
* IC7	X9465C00	IC.MEMORY	S29AL004D70TFI020	written	メモリIC	
IC8	X3693A00	IC	SN74LV245APWR TRAN		ロジックIC	
IC9	X3824A00	IC	SN74AHCT08PWR		ロジックIC	01
IC10	X3807A00	IC	AK4628VQ		IC	08
IC11	X5945A00	IC	PQ012FZ01ZPH		電源IC	05
IC12	X6051A00	IC	UPC29M33T-E1-AZ		電源IC	04
* IC13		IC.CPU			IC CPU	
IC14-15	X2331A00	IC	NJM4580E OP AMP		アンプIC	01
IC16	X5769A00	IC	KIA78L05BP		電源IC	02
IC17	X4325A00	IC	YAC523-EVR2		ICアナログ	06
Q1	VV556400	TR	2SC2412K Q,R,S		トランジスタ	01
Q2	WC435000	TR.DGT	KRC102S-RTK		デジタルトランジスタ	01
Q3	V4096100	TR	2SC4614 S,T		トランジスタ	02
Q4	V4096000	TR	2SA1770 S,T		トランジスタ	03
Q5	VV655000	TR.DGT	DTA114EKA		デジタルトランジスタ	01
Q6-8	VZ725900	TR	2SD1938F S,T		トランジスタ	01
R87	HV753100	R.CAR.FP	1Ω 1/4W		不燃化カーボン抵抗	01
R91-92	HV753100	R.CAR.FP	1Ω 1/4W		不燃化カーボン抵抗	01
R209	HV753100	R.CAR.FP	1Ω 1/4W		不燃化カーボン抵抗	01
R213-214	HV753100	R.CAR.FP	1Ω 1/4W		不燃化カーボン抵抗	01
ST200-201	WA789600	SCR.TERM	M3		スクリューターミナル	
ST302-303	WA789600	SCR.TERM	M3		スクリューターミナル	
SW300	VV011000	SW.TACT	SKHLLC		タクトSW	01
U300	WB437900	L.DTCT	GP1UD281YK		リモコン受光ユニット	04
XL1	V3625700	RSNR.CRYS	24.576MHz		水晶振動子	03
XL2	WA674700	RSNR.CE	16MHz CSTLS16M0X51		セラミック振動子	
* * *	WM892200	P.C.B.	MAIN	J	PCB MAIN	
	WM892400	P.C.B.	MAIN	RKAL	PCB MAIN	
	WM892500	P.C.B.	MAIN	G	PCB MAIN	
CB1	VB858600	CN.BS.PIN	7P		ベースピン	01
CB2	VB858900	CN.BS.PIN	10P		ベースピン	01
CB3	LB919070	CN.BS.PIN	7P		ベース付ポスト	01
CB4	VB389600	CN.BS.PIN	11P		コネクタベースポスト	01
CB8-9	WC050700	CLIP.FUSE	EYF-52BCY		ヒューズクリップ	01
CB10	V9377900	CN.BS.PIN	4P	RKAL	ベース付ポスト	
CB11	LB919060	CN.BS.PIN	6P		ベース付ポスト	01
CB12	LB933040	CN.BS.PIN	4P		ベースポスト	01
CB14	VG879900	CN.BS.PIN	2P		ベースピン	01
CB15	LB933020	CN.BS.PIN	2P		ベースポスト	01

* New Parts (新規部品)

NX-SW1000

P.C.B. MAIN

Ref No.	Part No.	Description	Remarks	Markets	部品名	ランク
CB16	VP245600	CN	2P		ベース付ポスト	01
C1-3	UR867100	C.EL	10uF 50V		ケミコン	01
C4-5	WJ602900	C.MYLAR	100pF 50V K		マイラーコン	01
C6	WJ605000	C.MYLAR	0.01uF 50V J		マイラーコン	01
C7-8	US061220	C.CE.CHP	22pF 50V B		チップセラコン	01
C9	UR867100	C.EL	10uF 50V		ケミコン	01
C10-11	WJ603100	C.MYLAR	220pF 50V		マイラーコン	
C12	VR169000	C.MYLAR	0.33uF 50V		マイラーコン	01
C13-14	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C15	VR168500	C.MYLAR.ML	ECQ-V1H154JL3		積層マイラーコン	01
C16-18	UR867100	C.EL	10uF 50V		ケミコン	01
C19-20	VR168600	C.MYLAR.ML	ECQ-V1H184JL3		積層マイラーコン	01
C21	UR837330	C.EL	33uF 16V		ケミコン	01
C22	UR867100	C.EL	10uF 50V		ケミコン	01
C23	VR168300	C.MYLAR	0.1uF 50V		マイラーコン	01
C24-25	UR837100	C.EL	10uF 16V		ケミコン	01
C28	UR838100	C.EL	100uF 16V		ケミコン	01
C29	UR877220	C.EL	22uF 63V		ケミコン	01
C30	WJ605000	C.MYLAR	0.01uF 50V J		マイラーコン	01
C31	UR897100	C.EL	10uF 100V		ケミコン	01
C32	UR877220	C.EL	22uF 63V		ケミコン	01
C33	UR897100	C.EL	10uF 100V		ケミコン	01
C34	WJ602900	C.MYLAR	100pF 50V K		マイラーコン	01
C35	WJ603300	C.MYLAR	470pF 50V J		マイラーコン	01
C36	WJ605000	C.MYLAR	0.01uF 50V J		マイラーコン	01
C37	WJ603300	C.MYLAR	470pF 50V J		マイラーコン	01
C38	VR169200	C.MYLAR	0.47uF 50V		マイラーコン	01
C39	WJ602900	C.MYLAR	100pF 50V K		マイラーコン	01
C40	UR867330	C.EL	33uF 50V		ケミコン	01
C41	WJ603300	C.MYLAR	470pF 50V J		マイラーコン	01
C42	UR897100	C.EL	10uF 100V		ケミコン	01
C43	FG650500	C.CE	5pF 50V		セラコン	01
C44	WJ602900	C.MYLAR	100pF 50V K		マイラーコン	01
C45	UR867330	C.EL	33uF 50V		ケミコン	01
C46-47	UR837470	C.EL	47uF 16V		ケミコン	01
C48	UR866100	C.EL	1uF 50V		ケミコン	01
C49-50	FG650500	C.CE	5pF 50V		セラコン	01
C51-53	UA654470	C.MYLAR	0.047uF 50V J		マイラーコン	01
C54	UR866470	C.EL	4.7uF 50V		ケミコン	01
C55	UR828220	C.EL	220uF 10V		ケミコン	01
C56	VR168300	C.MYLAR	0.1uF 50V		マイラーコン	01
C57	UR867100	C.EL	10uF 50V		ケミコン	01
C58	UR858100	C.EL	100uF 35V		ケミコン	01
C59	UA654220	C.MYLAR	0.022uF 50V J		マイラーコン	01
C60-61	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C62-63	UR866100	C.EL	1uF 50V		ケミコン	01
C64	US135100	C.CE.CHP	0.1uF 16V		チップセラコン	01
C65	UR866100	C.EL	1uF 50V		ケミコン	01
C66	UA654220	C.MYLAR	0.022uF 50V J		マイラーコン	01
C67	WJ605000	C.MYLAR	0.01uF 50V J		マイラーコン	01
C68	UR866100	C.EL	1uF 50V		ケミコン	01
C69	US064100	C.CE.CHP	0.01uF 50V B		チップセラコン	01
C70	WJ605000	C.MYLAR	0.01uF 50V J		マイラーコン	01
C71-72	UR866100	C.EL	1uF 50V		ケミコン	01

* New Parts (新規部品)

NX-SW1000

P.C.B. MAIN

Ref No.	Part No.	Description	Remarks	Markets	部品名	ランク
C75	UR866100	C.EL 1uF 50V			ケミコン	01
C78-79	WJ605000	C.MYLAR 0.01uF 50V J			マイラーコン	01
C80-81	WE514200	C.EL 6800uF 63V			ケミコン	
C83-84	UR749220	C.EL 2200uF 25V			ケミコン	03
C87	UR73A100	C.EL 10000uF 16V			ケミコン	03
C88-89	VR168300	C.MYLAR 0.1uF 50V			マイラーコン	01
C90-91	WJ611400	C.MYLAR 0.1uF 100V J			マイラーコン	01
C92	US135100	C.CE.CHP 0.1uF 16V			チップセラコン	01
C93	WJ605000	C.MYLAR 0.01uF 50V J			マイラーコン	01
C94	US064100	C.CE.CHP 0.01uF 50V B			チップセラコン	01
C95	WJ605000	C.MYLAR 0.01uF 50V J			マイラーコン	01
C96	VR168300	C.MYLAR 0.1uF 50V			マイラーコン	01
△ C97	WB121400	C.CE.SAFETY 0.01uF 295V			規格認定コンデンサ	
C100-101	WJ605000	C.MYLAR 0.01uF 50V J			マイラーコン	01
D1-4	VD631600	DIODE 1SS133,176			ダイオード	01
D5	VU992600	DIODE.ZENR MA8051-M 5.1V			ツェナーダイオード	01
D6-7	VD631600	DIODE 1SS133,176			ダイオード	01
D8-9	WC398800	DIODE KDS160-RTK			ダイオード	01
D10	VN008700	DIODE 1SS270A			ダイオード	01
D11-14	VD631600	DIODE 1SS133,176			ダイオード	01
D15	VN008700	DIODE 1SS270A			ダイオード	01
D16	VD631600	DIODE 1SS133,176			ダイオード	01
D17-18	VN008700	DIODE 1SS270A			ダイオード	01
D19	VD631600	DIODE 1SS133,176			ダイオード	01
D20-21	VT332900	DIODE 1SS355			ダイオード	01
△ D23	WA653100	DIODE.BRG KBP103G 1A 200V			ダイオードブリツジ	02
△ D24	WA653200	DIODE.BRG TS6P03G 6A 200V			ダイオードブリツジ	04
D25-26	WC398800	DIODE KDS160-RTK			ダイオード	01
△ D27	WJ286700	DIODE.BRG RS403M 4A 140V			ダイオードブリツジ	03
D28	VU994600	DIODE.ZENR MA8082-M 8.2V			ツェナーダイオード	01
△ F1	WB760600	FUSE T6.3A 250V		JRKAL	ヒューズ	01
△ F1	VV071700	FUSE 3.15A 250V		GF	ヒューズ	01
△ IC1-4	X2331A00	IC NJM4580E OP AMP			アンプ I C	01
△ IC7	X8190A00	IC STK433-330-E			パワー I C	12
△ IC10	X4153A00	IC KIA7812API			電源 I C	02
△ IC11	X4154A00	IC KIA7912PI			電源 I C	
△ IC12	X4928A00	IC KIA7805API 5V			電源 I C	02
△ IC14	X0515A00	IC LM61CIZ THERMAL			電源 I C	03
△ Q6	WC398400	TR 2N5551C-AT			トランジスタ	01
△ Q7-8	VC614000	TR 2SB1274 Q,R,S			トランジスタ	02
△ Q9	WC398400	TR 2N5551C-AT			トランジスタ	01
△ Q10-11	WC397700	TR 2N5401C-AT			トランジスタ	
Q12	WB228800	TR KTC3198 Y AT			トランジスタ	
Q13	WB228700	TR KTA1266 Y AT			トランジスタ	
Q14	WB228800	TR KTC3198 Y AT			トランジスタ	
Q15	WB228700	TR KTA1266 Y AT			トランジスタ	
△ Q16-18	WC398400	TR 2N5551C-AT			トランジスタ	01
△ Q19	WC397700	TR 2N5401C-AT			トランジスタ	
Q20	V3028000	FET 2SK304 E			F E T	01
△ Q21-22	WC434900	TR.DGT KRA104S-RTK			デジタルトランジスタ	01
Q23-24	WC435000	TR.DGT KRC102S-RTK			デジタルトランジスタ	01
△ Q25-26	iC181510	TR 2SC1815 Y			トランジスタ	01
Q27	WC435100	TR.DGT KRC104S-RTK			デジタルトランジスタ	01
Q28	VV556400	TR 2SC2412K Q,R,S			トランジスタ	01

* New Parts (新規部品)


NX-SW1000

P.C.B. MAIN

Carbon Resistors

	Ref No.	Part No.	Description	Remarks	Markets	部品名	ランク
	Q30-31	WC435000	TR.DGT	KRC102S-RTK		デジタルトランジスタ	01
	R36	WC796900	R.MTL.FLM	2.7KΩ 1/4W		金属被膜抵抗	
△	R39	HV753220	R.CAR.FP	2.2Ω 1/4W		不燃化カーボン抵抗	01
△	R42	HV755560	R.CAR.FP	560Ω 1/4W		不燃化カーボン抵抗	01
△	R52	HV754100	R.CAR.FP	10Ω 1/4W		不燃化カーボン抵抗	01
△	R55	HV754100	R.CAR.FP	10Ω 1/4W		不燃化カーボン抵抗	01
	R69	HV754470	R.CAR.FP	47Ω 1/4W		不燃化カーボン抵抗	01
△	R71	WB279900	R.CEMENT	RG55C 0.22+0.22		セメント抵抗	02
	R78	WC798300	R.MTL.FLM	10KΩ 1/4W		金属被膜抵抗	
△	R79-80	WB279900	R.CEMENT	RG55C 0.22+0.22		セメント抵抗	02
	R86	WC798300	R.MTL.FLM	10KΩ 1/4W		金属被膜抵抗	
	R87	WC799000	R.MTL.FLM	20KΩ 1/4W		金属被膜抵抗	
	R93	HV754100	R.CAR.FP	10Ω 1/4W		不燃化カーボン抵抗	01
	R94	WC798300	R.MTL.FLM	10KΩ 1/4W		金属被膜抵抗	
	R96-97	HV754100	R.CAR.FP	10Ω 1/4W		不燃化カーボン抵抗	01
△	R99	WB625100	R.MTL.FLM	4.7Ω 1W J		金属被膜抵抗	01
△	R104-105	WB625100	R.MTL.FLM	4.7Ω 1W J		金属被膜抵抗	01
	R119	V6022600	R.CEMENT	0.1Ω 3W		セメント抵抗	
	R133	HV753470	R.CAR.FP	4.7Ω 1/4W		不燃化カーボン抵抗	01
	R138	HV753470	R.CAR.FP	4.7Ω 1/4W		不燃化カーボン抵抗	01
△	R140-141	HV753100	R.CAR.FP	1Ω 1/4W		不燃化カーボン抵抗	01
△*	R142	WB624300	R.MTL.FLM	0.22Ω 1W		金属被膜抵抗	
△	R152	WH819500	R.FUSE	0.47Ω 1W		ヒューズ抵抗	01
△	RY1-2	WJ122400	RELAY	981-2A-24DS-SP7		リレー 2 4 V	04
△	RY3	V2712300	RELAY	DC SDT-S-112LMR		リレー 1 2 V	05
△	SW6	WC906700	SW.SLIDE	SDKPA40300	RKAL	スライドSW	06
	TE1	WH963000	TERM.SP	4P LTS0410-0015FM	J	スピーカーターミナル	05
*	TE1	WH963100	TERM.SP	4P LTS0410-0016FM	RKAGFL	スピーカーターミナル	
△	TE2	WB782600	AC INLET	R-30190(26)	RKAL	ACインレット 2 P	
		WE774200	SCR.BND.HD	3x10 MFZN2W3		バインドBタイトネジ	01


Value	1/4W Type Part No.	1/6W Type Part No.	Value	1/4W Type Part No.	1/6W Type Part No.
1.0 Ω	HJ35 3100	HF85 3100	10 kΩ	HF45 7100	HF45 7100
1.8 Ω	HJ35 3180	※	11 kΩ	HF45 7110	HF45 7110
2.2 Ω	HJ35 3220	HF85 3220	12 kΩ	HJ35 7120	HF85 7120
3.3 Ω	HJ35 3330	HF85 3330	13 kΩ	HF45 7130	HF45 7130
4.7 Ω	HJ35 3470	HF85 3470	15 kΩ	HF45 7150	HF45 7150
5.6 Ω	HJ35 3560	HF85 3560	18 kΩ	HF45 7180	HF45 7180
10 Ω	HF45 4100	HF45 4100	22 kΩ	HF45 7220	HF45 7220
15 Ω	HJ35 4150	HF85 4150	24 kΩ	HF45 7240	HF45 7240
22 Ω	HF45 4220	HF45 4220	27 kΩ	HJ35 7270	HF85 7270
27 Ω	HJ35 4270	HF85 4270	30 kΩ	HF45 7300	HF45 7300
33 Ω	HF45 4330	HF45 4330	33 kΩ	HF45 7330	HF45 7330
39 Ω	HJ35 4470	HF85 4390	36 kΩ	HF45 7360	HF45 7360
47 Ω	HF45 4470	HF45 4470	39 kΩ	HF45 7390	HF45 7390
56 Ω	HF45 4560	HF45 4560	47 kΩ	HF45 7470	HF45 7470
68 Ω	HF45 4680	HF45 4680	51 kΩ	HF45 7510	HF45 7510
75 Ω	HF45 4750	HF45 4750	56 kΩ	HF45 7560	HF45 7560
82 Ω	HF45 4820	HF45 4820	62 kΩ	HF45 7620	HF45 7620
91 Ω	HF45 4910	HF45 4910	68 kΩ	HF45 7680	HF45 7680
100 Ω	HF45 5100	HF45 5100	82 kΩ	HF45 7820	HF45 7820
110 Ω	HJ35 5110	HF85 5110	91 kΩ	HF45 7910	HF45 7910
120 Ω	HF45 5120	HF45 5120	100 kΩ	HF45 8100	HF45 8100
150 Ω	HF45 5150	HF45 5150	110 kΩ	HF45 8110	HF45 8110
160 Ω	HJ35 5160	※	120 kΩ	HF45 8120	HF45 8120
180 Ω	HF45 5180	HF45 5180	150 kΩ	HF45 8150	HF45 8150
200 Ω	HF45 5200	HF45 5200	180 kΩ	HF45 8180	HF45 8180
220 Ω	HF45 5220	HF45 5220	220 kΩ	HJ35 8220	HF85 8220
270 Ω	HF45 5270	HF45 5270	270 kΩ	HF45 8270	HF45 8270
330 Ω	HF45 5330	HF45 5330	300 kΩ	HF45 8300	HF45 8300
390 Ω	HF45 5390	HF45 5390	330 kΩ	HF45 8330	HF45 8330
430 Ω	HF45 5430	HF45 5430	390 kΩ	HJ35 8390	HF85 8390
470 Ω	HF45 5470	HF45 5470	470 kΩ	HF45 8470	HF45 8470
510 Ω	HF45 5510	HF45 5510	560 kΩ	HJ35 8560	HF85 8560
560 Ω	HF45 5560	HF45 5560	680 kΩ	HJ35 8680	HF85 8680
680 Ω	HF45 5680	HF45 5680	820 kΩ	HJ35 8820	HF85 8820
820 Ω	HF45 5820	HF45 5820	1.0 MΩ	HF45 9100	HF45 9100
910 Ω	HF45 5910	HF45 5910	1.2 MΩ	HJ35 9120	※
1.0 kΩ	HF45 6100	HF45 6100	1.5 MΩ	HJ35 9150	HF85 9150
1.2 kΩ	HF45 6120	HF45 6120	1.8 MΩ	HJ35 9180	HF85 9180
1.5 kΩ	HF45 6150	HF45 6150	2.2 MΩ	HJ35 9220	HF85 9220
1.8 kΩ	HF45 6180	HF45 6180	3.3 MΩ	HJ35 9330	HF85 9330
2.0 kΩ	HJ35 6200	HF85 6200	3.9 MΩ	HJ35 9390	※
2.2 kΩ	HF45 6220	HF45 6220	4.7 MΩ	HJ35 9470	HF85 9470
2.4 kΩ	HJ35 6240	HF85 6240			
2.7 kΩ	HF45 6270	HF45 6270			
3.0 kΩ	HF45 6300	HF45 6300			
3.3 kΩ	HF45 6330	HF45 6330			
3.6 kΩ	HJ35 6360	HF85 6360			
3.9 kΩ	HF45 6390	HF45 6390			
4.7 kΩ	HF45 6470	HF45 6470			
5.1 kΩ	HF45 6510	HF45 6510			
5.6 kΩ	HF45 6560	HF45 6560			
6.8 kΩ	HF45 6680	HF45 6680			
8.2 kΩ	HF45 6820	HF45 6820			
9.1 kΩ	HF45 6910	HF45 6910			




* New Parts (新規部品)

● ACCESSORIES


For DVR-1000



For NX-SW1000



For NX-P1000



Ref No.	Part No.	Description	Remarks	Markets	部品名	ランク
* 101	AAX89440	TOP CABINET	3139 244 17561		トップキャビネット	
* 119	AAX89540	BUTTON VOLUME DVR1000	3139 244 17572		ボタンVOLUME	
* 120	AAX89510	BUTTON INPUT/STOP	3139 244 17852		ボタンINPUT/STOP	
* 121	AAX89520	BUTTON PLAY/PAUSE	3139 244 17862		ボタンPLAY/PAUSE	
* 122	AAX89530	BUTTON STANDBY	3139 244 17581		ボタンSTANDBY	
* 123	AAX89500	BUTTON EJECT	3139 244 17591		ボタンEJECT	
* 124	AAX89300	ESCUTCHEON BUTTON	3139 244 17601		エスカッション ボタン	
* 125	AAX89600	LENS LED	3139 244 17611		レンズLED	
* 126	AAX89420	SHEET GUIDE	3139 244 17622		シート ガイド	
* 127	AAX89480	PANEL GUIDE	3139 243 10241		パネル ガイド	
* 128	AAX89400	SHEET WINDOW	3139 244 17632	J	シート ウィンドウ	
* 128	AAX89410	SHEET WINDOW	3139 244 17642	RKAGFL	シート ウィンドウ	
* 130	AAX89460	TOP PANEL	3139 241 60952	J	トップパネル	
* 130	AAX90120	TOP PANEL	3139 241 60992	RKAGFL	トップパネル	
* 150	AAX89550	BOTTOM CABINET ASS'Y	3141 079 44241		ボトムキャビネットASS'Y	
* 152	AAX89430	SHEET BARRIER	3139 244 17681		シート バリア	
* 163	AAX89560	REAR PANEL	3139 241 27201	J	リアパネル	
* 163	AAX89580	REAR PANEL	3139 241 27222	RKAL	リアパネル	
* 163	AAX89570	REAR PANEL	3139 241 27211	G	リアパネル	
* 163	AAX89590	REAR PANEL	3139 241 27231	F	リアパネル	
250	AAX53520	PAN HEAD TORX P-TIGHT SCREW	3x8 MFZN2BL 2511 076 50012		ナベトルクスPタイトネジ	
251	AAX23640	PAN HEAD TORX S-TIGHT SCREW	3x6 MFZN2BL 2511 077 00039		ナベトルクスSタイトネジ	
* 252	AAX89470	PAN HEAD TORX P-TIGHT SCREW	3x8 MFZN2BL 2511 077 00041		ナベトルクスPタイトネジ	
* 282	AAX89640	SPECIAL SCREW	2.6x4 MFZN2BL 2522 200 00088		特殊小ネジ	
290	AAX72210	PAN HEAD TORX P-TIGHT SCREW	3x6 MFZN2BL 2511 076 50011		ナベトルクスPタイトネジ	01
* 1001	AAX89250	P.C.B. ASS'Y	FRONT 3139 248 53461	J	P C B FRONT	
* 1001	AAX89240	P.C.B. ASS'Y	FRONT 3139 248 53451	RKAGFL	P C B FRONT	
* 1002	AAX89280	P.C.B. ASS'Y	USB 3139 248 53331		P C B USB	
* 1003	AAX89270	P.C.B. ASS'Y	MONO SD6.3 3139 248 53351		P C B MONO	
* 1004	AAX89260	P.C.B. ASS'Y	HDMI 3139 248 53361		P C B HDMI	
△ * 1006	AAX89630	POWER SUPPLY UNIT	06P30 WR AC6812-8LF 3139 247 12562		電源ユニット	
* 1007	AAX89610	LOADER ASS'Y	SLOT IN type 3139 248 00611		ローダーASS'Y	
* 1008	AAX89190	AM/FM TUNER	ENG04815QF 2422 542 00047	J	AM/FMチューナー	
* 1008	AAX89180	AM/FM TUNER	ENG06833QF 2422 542 00045	RKAL	AM/FMチューナー	
* 1008	AAX89170	AM/FM TUNER	ENG07820QF 2422 542 00044	GF	AM/FMチューナー	
* 1009	AAX89230	P.C.B. ASS'Y	AV 3139 248 53431	J	P C B AV	
* 1009	AAX89210	P.C.B. ASS'Y	AV 3139 248 53341	RKAL	P C B AV	
* 1009	AAX89220	P.C.B. ASS'Y	AV 3139 248 53421	GF	P C B AV	
△ * 8002	AAX89390	CABLE ASS'Y	2P 140mm 3139 241 03551	JGF	ケーブルASS'Y	
△ * 8002	AAX80010	CABLE ASS'Y	2P 140mm 3139 241 03121	RKAL	ケーブルASS'Y	
* 8005	AAX89320	FLEXIBLE FLAT CABLE	16P 180mm P=1mm 3139 111 02361		カード電線 C & C	
* 8007	AAX89370	FLEXIBLE FLAT CABLE	21P 140mm P=1mm 3139 241 03991		カード電線 C & C	
* 8008	AAX89360	FLEXIBLE FLAT CABLE	30P 140mm P=1mm 3139 241 02771		カード電線 C & C	
8009	AAX59250	FLEXIBLE FLAT CABLE	30P 180mm P=1mm 3139 241 00421		カード電線 C & C	02
8010	AAX90100	FLEXIBLE FLAT CABLE	30P 280mm P=1mm FOLD 3139 241 04011		カード電線 C & C	
* 8011	AAX89330	FLEXIBLE FLAT CABLE	10P 180mm P=1.25mm 3139 111 04471		カード電線 C & C	
* 8012	AAX89340	FLEXIBLE FLAT CABLE	10P 180mm P=1mm 3139 241 01771		カード電線 C & C	
* 8013	AAX89350	FLEXIBLE FLAT CABLE	19P 220mm P=1mm 3139 241 02451		カード電線 C & C	
* 8014	AAX47130	FLEXIBLE FLAT CABLE	11P 80mm P=1mm 3139 241 00231		カード電線 C & C	
8015	AAX62220	FLEXIBLE FLAT CABLE	13P 220mm P=1mm 3139 241 00571		カード電線 C & C	01
* 8016	AAX90110	FLEXIBLE FLAT CABLE	7P 100mm P=1mm 3139 241 04121		カード電線 C & C	
* 8017	AAX89380	FLEXIBLE FLAT CABLE	9P 80mm P=1mm 3139 241 04001		カード電線 C & C	
* 8022	AAX89290	USB CABLE ASS'Y	USB 5P 300mm 2422 076 00786		USBケーブルASS'Y	

* New Parts (新規部品)


Ref No.	Part No.	Description	Remarks	Markets	部品名	ランク
* 2000	WM238600	FOR DVR-1000 REMOTE CONTROL		JRKAL	リモコン	
* 2000	WM238700	REMOTE CONTROL		GF	リモコン	
2000-1	AAX57560	BATTERY COVER	103RRS-141-07L		電池蓋	
2002	AAX67120	INDOOR FM ANTENNA	1.0m 1pc 2422 076 00546		F M簡易アンテナ	01
* 2003	AAX89200	AM LOOP ANTENNA	1.0m 1pc 2422 549 00717	J	A Mループアンテナ	
2003	AAX67100	AM LOOP ANTENNA	1.0m 1pc 2422 549 45386	RKAL	A Mループアンテナ	04
△ * 2004	AAX89620	POWER CABLE for DVR-1000	1.5m 1pc 2422 070 00124	J	電源コード	
△ 2004	AAX79660	POWER CABLE for DVR-1000	1.5m 1pc 2422 070 98151	RKAGFL	電源コード	
△ 2005	AAX79950	POWER CABLE for DVR-1000	1.5m 1pc 2422 070 98242	RKAL	電源コード	
△ 2006	AAX79940	POWER CABLE for DVR-1000	1.5m 1pc 2422 070 00094	RKAL	電源コード	
* 2007	AAX89490	VIDEO PIN CABLE BATTERY	1P YE 1.5m 1pc 2422 076 00831 R6,AA,UM-3 2pcs		ビデオ用ピンケーブル 単3乾電池	
* 2010	WM885500	FOR NX-SW1000 SYSTEM CONTROL CABLE	13P 4m LLM5335-4000FC		システム接続ケーブル	
△ 2011	WK391000	POWER CABLE for NX-SW1000	2m 1pc	R	電源コード	
△ 2011	WH641300	POWER CABLE for NX-SW1000	2m 1pc	K	電源コード	
△ 2011	WB750900	POWER CABLE for NX-SW1000	2m 1pc	A	電源コード	
△ 2011	V7704900	POWER CABLE for NX-SW1000	2m 1pc	L	電源コード	
* 2020	AAX88980	FOR NX-P1000 SPEAKER CABLE ASS'Y	4m 2pcs 468879		S PケーブルASS'Y	

* New Parts (新規部品)

DVX-1000

NX-SW1000

● OVERALL ASS'Y




Ref No.	Part No.	Description	Remarks	Markets	部品名	ランク
* 1-1	WM907300	FRONT PANEL SUB ASS'Y	with PANEL/GRILLE		F パネルサブ A S S Y	
1-2	WC904800	EMBLEM			エンブレム	02
* 2-1	WM892200	P.C.B. ASS'Y	MAIN	J	P C B M A I N	
* 2-1	WM892400	P.C.B. ASS'Y	MAIN	RKAL	P C B M A I N	
* 2-1	WM892500	P.C.B. ASS'Y	MAIN	GF	P C B M A I N	
* 2-2	WM892700	P.C.B. ASS'Y	DSP		P C B D S P	
⚠ 2-4	X9495A00	POWER TRANSFORMER		J	電源トランス	
⚠ 2-4	X9497A00	POWER TRANSFORMER		RKAL	電源トランス	
⚠ 2-4	X9496A00	POWER TRANSFORMER		GF	電源トランス	
⚠ 2-5	WM857700	POWER CABLE	1.8m	J	電源コード	
⚠ 2-5	WB212300	POWER CABLE	2m	GF	電源コード	
2-6	V2438700	CORD STOPPER	10P1	JGF	コードストッパー	02
* 2-11	WM147100	REAR PANEL		J	リアパネル	09
* 2-11	WM147200	REAR PANEL		RKAL	リアパネル	
* 2-11	WM147500	REAR PANEL		GF	リアパネル	
* 2-18	WM140100	COVER DSP			カバー／D S P	
2-31	WF765200	PW HEAD S-TIGHT SCREW	4x8-10 MFZN2B3		PWヘッドSタイトネジ	01
2-32	WE774400	BIND HEAD B-TIGHT SCREW	3x8 MFZN2B3		バインドBタイトネジ	01
2-33	WE774600	SCREW IC	3x18 MFZN2W3		スクリュー I C	01
2-34	WF002600	PW HEAD B-TIGHT SCREW	3x8 MFZN2W3		PWヘッドBタイトネジ	01
* 2-37	WM905600	PAN HEAD SCREW	2.6x6 MFZN2B3		ナベ小ネジ	
2-38	WE774100	BIND HEAD BONDING B-T. SCREW	3x8 MFZN2B3		ボンディングBタイトネジ	01
2-39	WE774800	BIND HEAD P-TIGHT SCREW	3x8 MFZN2W3	RKAL	バインドPタイトネジ	01
* 3	WM224900	CABINET ASS'Y			キャビネット A S S Y	
* 4	X9379A00	DRIVER WOOFER	16cm 6Ω	JA16B3	スピーカーユニット	
* 5	WM139900	REAR COVER			リアカバー	
* 6	WM179700	LEG			レッグ	01
* 7	WM727200	PAD	D25 t=2		パッド	
8	WC739000	BUSHING			ブッシュ	
21	WF459800	BIND HEAD TAPPING SCREW	4x25 MFZN2B3		バインド T P ネジ	01

* New Parts (新規部品)

NX-P1000

● OVERALL ASS'Y



Ref No.	Part No.	Description	Remarks	Markets	部品名	ランク
* 1	X9488A00	DRIVER WOOFER	12cm 6Ω with CABLE	467388	スピーカーユニット	
* 2	X9489A00	DRIVER TWEETER	2.5cm 6Ω	467389	スピーカーユニット	
* 3	AAX89070	NETWORK ASS'Y		469358	ネットワークA S S Y	
* 3-3	AAX89150	CEMENT RESISTOR	R1 3Ω 5W	473855	セメント抵抗	
* 3-4	AAX89030	ELECTROLYTIC CAPASITOR	C2 3.9uF 63V	468738	ケミコン	
* 3-5	AAX88970	ELECTROLYTIC CAPASITOR	C1 6.8uF 63V	468739	ケミコン	
* 4	AAX89020	CABINET AL ASS'Y		470429	キャビネットA S S Y	
* 4-4	AAX89060	WASHER TERMINAL	D13.5/9 t=2.5	466787	ターミナルワッシャー	
* 4-6	AAX89040	SPEAKER TERMINAL ASS'Y	RED	430484	スピーカー端子A S S Y	
* 4-7	AAX89050	SPEAKER TERMINAL ASS'Y	BLACK	430485	スピーカー端子A S S Y	
* 5	AAX89120	FRONT PANEL ASS'Y	with GRILLE/EMBLEM	470430	フロントパネルA S S Y	
* 6	AAX89000	COVER TOP ASS'Y	with TW.CABLE	470431	カバートップA S S Y	
* 7	AAX89010	COVER BOTTOM ASS'Y		470432	カバーボトムA S S Y	
* 18	AAX89140	DAMPING MATERIAL ASS'Y	120x90x20	474135	防振材	
* 23	AAX89130	NONSKID PAD (FOOT)	D20 t=2	385076	滑り止めパッド	
* 30	AAX89090	BIND HEAD P-TIGHT SCREW	3x8 MFZN2B3	407446	バインドPタイトネジ	
* 31	AAX89080	BIND HEAD B-TIGHT SCREW	4x16 MFZN2B3	426567	バインドBタイトネジ	
* 32	AAX89110	BIND HEAD SCREW	5x8 MFZN2B3	422361	バインド小ネジ	
* 33	AAX89100	BIND HEAD P-TIGHT SCREW	3x12 MFZN2B3	421752	バインドPタイトネジ	
* 34	AAX88990	GRILLE TWEETER ASS'Y		474136	TWグリルA S S Y	

* New Parts (新規部品)

● NETWORK CIRCUIT DIAGRAM

